



Parts List					Qty	Comment	Footnote
Ref	Class	Part	Description				
1	32	52951A	TUBING, HYDRAULIC PUMP TO	1			
1	32	58432A	TUBING, HYDRAULIC PUMP TO	1			
2	22	49718	NUT, COMPRESSION-HYDRAULI	2			
3	32	55816	HOSE, HYDRAULIC-CONNECTOF	1			
3	32	59841	HOSE, HYDRAULIC-CONNECTOF	1			
4	32	59842	HOSE, HYDRAULIC-CONNECTOF	1			
5	32	86036	HOSE, HYDRAULIC-CONNECTOF	4			
6		45706A	TRIM CYLINDER ASSEMBLY, COI	2	SEE NEXT PAGE FOR REPAIR F		
-		45522A	PIVOT END REPAIR KIT, TRIM	2	SEE NEXT PAGE FOR REPAIR F		
-		77442A	OUTER TUBE REPAIR KIT, TRI	2	SEE NEXT PAGE FOR REPAIR F		
-	25	60342A	"O" RING REPAIR KIT, TRIM C	2	SEE NEXT PAGE FOR REPAIR F		
7	17	45735	PIN, FRONT ANCHOR-TRIM CYLI	1			
8	12	45737	WASHER, FRONT ANCHOR PIN	2			
9	32	89574	BUSHING, RUBBER-FRONT ANCI	4			
10	24	46312	SPRING, FRONT ANCHOR PIN	2			
11	12	46765	WASHER, FRONT ANCHOR PIN	2			
12	11	34932	NUT, FRONT ANCHOR PIN	2			
13	17	45738	PIN, REAR ANCHOR-TRIM CYLIN	1			
14	12	45737	WASHER, REAR ANCHOR PIN	2			
15	23	89574	BUSHING, RUBBER-REAR ANCH	4			
16	12	46765	WASHER, RAER ANCHOR PIN	2			
17	11	34932	NUT, REAR ANCHOR PIN	2			
--	24	86687A	SPRING CONTINUINTY KIT	1			