



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	50	46282	STARTER MOTOR ASSEMBLY	1	SEE NOTE SERIAL 00000000-02	
1	50	59799	STARTER MOTOR ASSEMBLY	1	SEE NOTE SERIAL 03128229-09	
2	10	34545	BOLT, STARTER MOTOR MOUN	1		
3	10	34544	BOLT, STARTER MOTOR MOUN	1		
4		52250	BRACE, STARTER MOTOR	1	SERIAL 00000000-02816416	
4		54671	BRACE, STARTER MOTOR	1	SERIAL 02816417-09999999	
5	16	52387	STUD, BRACE TO MOTOR AND C	2		
6	12	20103	WASHER, BRACE STUD	2	SERIAL 00000000-02816416	
7	11	35814	NUT, BRACE STUD	2	SERIAL 00000000-02816416	
7	11	25594	NUT, BRACE STUD	2	SERIAL 02816417-09999999	
8	11	28517	NUT, SOLENOID SWITCH TERMI	1		
9	11	26419	NUT, SOLENOID SWITCH TERMI	1		
10	13	26395	LOCKWASHER, STARTER MOTO	1		
11	11	26419	NUT, STARTER MOTOR TERMIN	1		
10	13	26396	LOCKWASHER, STARTER MOTO	1		
11	11	20645	NUT, STARTER MOTOR TERMIN	1		
12		37615A 1	ALTERNATOR ASSEMBLY	1	SEE NOTE SERIAL 00000000-02	
12		56045	ALTERNATOR ASSEMBLY	1	SEENOTE SERIAL 02819267-02	
12		59755	ALTERNATOR ASSEMBLY	1	SEENOTE SERIAL 03128229-09	
13		53476	BRACE, ALTERNATOR TO CYLIN	1	SERIAL 00000000-02816416	
14	10	27165	SCREW, ALTERNATOR BRACE T	1	SERIAL 00000000-02816416	
15	13	37459	LOCKWASHER, ALTERNATOR BI	1	SERIAL 00000000-02816416	
16	12	20553	WASHER, ALTERNATOR BRACE	1	SERIAL 00000000-02816416	
13		58333	BRACE, ALTERNATOR TO CYLIN	1	SERIAL 02816417-09999999	
17	16	54177	STUD, ALTERNATOR BRACE TO	1	SERIAL 02816417-09999999	
18	12	20553	WASHER, ALTERNATOR BRACE	1	SERIAL 02816417-09999999	
19	11	23161	NUT, ALTERNATOR BRACE STU	1	SERIAL 02816417-09999999	
20	10	29198	SCREW, ALTERNATOR BRACE T	1		
21	12	26168	WASHER, ALTERNATOR BRACE	1		
22	10	32775	SCREW, ALTERNATOR TO BRAC	1	SERIAL 00000000-02816416	
23	23	32727	SPACER, ALTERNATOR SCREW	1	SERIAL 00000000-02816416	
22	10	37626	SCREW, ALTERNATOR TO BRAC	1	SERIAL 02816417-09999999	
23	23	56777	SPACER, ALTERNATOR TO BRAI	1	SERIAL 02816417-09999999	
24	12	25970	WASHER, ALTERNATOR TO BR/	2	SERIAL 02816417-09999999	
25	11	23161	NUT, ALTERNATOR SCREW	1		
26	16	54177	STUD, MOUNTING BRACKET TO	1	SERIAL 00000000-02816416	
27	16	54176	STUD, MOUNTING BRACKET TO	1	SERIAL 00000000-02816416	
28	27	53502	GASKET, ALTERNATOR MOUNTI	1	SERIAL 00000000-02816416	
29		52817	BRACKET, ALTERNATOR MOUN	1	SERIAL 00000000-02816416	
30		52818	BRACKET, ALTERNATOR MOUN	1	SERIAL 00000000-02816416	
31	12	20553	WASHER, MOUNTING BRACKET	2	SERIAL 00000000-02816416	