



			Parts List			
Ref	Class	Part	Description	Qty	Comment	Footnote
1		62424	DISTRIBUTOR ASSEMBLY COMF	1		
2		62426	SCREEN, VENT - DISTRIBUTOR	2		
3	43	33664	GEAR, DRIVE - MAIN SHAFT	1		
4		58237	MAIN SHAFT AND WEIGHT PL	1		
5	17	33649	PIN, DRIVE GEAR TO MAIN SHAF	1		
6		58235	CAM, BREAKER - ADVANCE	1		
-	12	58220	WASHER, CAM AND SHAFT	1		
-	26	58219	SEAL, HOUSING	1		
-		33653	FELT, BREAKER CAM LUBRICA	1		
-		33670	RETAINER, BREAKER CAM LUB	1		
7		33769	WEIGHT, BREAKER CAM ADVA	2		
8	24	58236	SPRING, BREAKER CAM ADVA	2		
9		33655	PLATE, WEIGHT HOLD DOWN	1		
10	10	33722	SCREW, WEIGHT HOLD DOWN	2		
11		33665	PLATE, MOUNTING - BREAKER	1		
12	10	33648	SCREW, MOUNTING PLATE TC	2		
12A	12	62425	WASHER, BREAKER PLATE SL	2		
13		33662	CONDENSER	1		
--		48024	BRACKET, CONDENSER MOUN	1		
--	10	48021	SCREW, CONDENSER BRACKE	1		
14		34235	BREAKER ASSEMBLY, DISTR	1		
15	10	33650	SCREW, BREAKER ASSEMBLY	1		
16	25	33666	GROMMET, MOUNTING PLATE	1		
17		48025	LEAD, PRIMARY	1		
18		58217	ROTOR, DISTRIBUTOR	1		
19	12	36275	WASHER, ROTOR	1		
20		33667	CAP, DISTRIBUTOR	1		
21		33654	BUTTON, CARBON - DISTRIB	1		
22	10	33660	SCREW, DISTRIBUTOR CAP TC	1		
23	10	33663	SCREW, DISTRIBUTOR CAP SL	1		
24	27	34486	GASKET, DISTRIBUTOR	1		
25	84	69713 1	LEAD ASSEMBLY, HIGH TENSIO	2		
26	84	69713 2	LEAD ASSEMBLY, HIGH TENSIO	2		
27		47604A 1	PROTECTOR, HIGH TENSION L	4		
--		60096	SLEEVE, TERMINAL END COVE	4		
28	33	54527	SPARK PLUG (AC#CR 44N) - NON	4		
28	33	59571	SPARK PLUG (AC#R43T) - TAPE	4		
29		32782	RETAINER, HIGH TENSION LEA	1		
30		32763A 1	WIRE ASSEMBLY, DISTRIBUTOR	1	SERIAL 03332138-03771644	
31		26433	COIL, IGNITION	1	SERIAL 03332138-03771644	
32		22221	BRACKET, IGNITION COIL MOUN	1	SERIAL 03332138-03771644	