



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	424	3864	CAMSHAFT	1		
2	28	34466	KEY, CAMSHAFT GEAR LOCATI	1		
3	23	34469	BEARING, CAMSHAFT THRUST	1		
4	43	58283	GEAR, TIMING - CAMSHAFT	1		
5	10	21417A 1	SCREW, TIMING GEAR TO CAMS	2		
6		46744	LIFTER, HYDRAULIC - TAPPET	8		
7		65142	WATER PUMP ASSEMBLY	1	SERIAL 03332138-03462607	
7		52353	WATER PUMP ASSEMBLY	1	SERIAL 03462608-09999999	
8	27	33956	GASKET, WATER PUMP	1		22
9	10	34471	SCREW, WATER PUMP TO CYLIN	2		
10	10	34505	SCREW, WATER PUMP TO CYLIN	2		
11		52349	PULLEY, WATER PUMP	1		
12	10	47277	SCREW, PULLEY TO WATER PU	4		
13	13	39107	LOCKWASHER, PULLEY SCREW	4		
14	32	46471	NOZZLE, OIL - TIMING GEAR	1		
15	57	32850	BELT, ALTERNATOR AND WATE	1	SERIAL 03332138-03462607	
15	57	64032	BELT, ALTERNATOR AND WATE	1	SERIAL 03462608-09999999	
16	613	3817	CONNECTING ROD ASSEMBLY	4		
17	10	52269	BOLT, CONNECTING ROD BEA	8		
18	11	37493	NUT, CONNECTING ROD CAP E	8		
19	23	52221	BEARING(PAIR), CONN. ROD(ST/	4		
19	23	52222	BEARING(PAIR), CONN. ROD(.00	AR		
19	23	52223	BEARING(PAIR), CONN. ROD(.00	AR		
19	23	52224	BEARING(PAIR), CONN. ROD(.01	AR		
19	23	52225	BEARING(PAIR), CONN. ROD(.02	AR		
20	423	3816	CRANKSHAFT	1		
21	28	34466	KEY, PULLEY AND GEAR LOCATI	2		
22	43	46743	GEAR, TIMING - CRANKSHAFT	1		
23		55045	BALANCER, HARMONIC	1		
24	220	2282	FLYWHEEL, CRANKSHAFT	1		
25	16	32808	STUD, FLYWHEEL TO ENGINE C	6		
26		32492A 5	ENGINE COUPLING ASSEMBLY	1		
27	12	35935	WASHER, FLYWHEEL STUD	6		
28	11	34933	NUT, FLYWHEEL STUD	6		