



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	1351	<b>4293A 1</b>	CARBURETOR ASSEMBLY, COM	1	SERIAL 03332138-03771644	
1	1351	<b>5203A 1</b>	CARBURETOR ASSEMBLY, COM	1	SERIAL 03771645-09999999	
1		N.S.S.	AIR HORN (ROCHESTER #7041)	1		
2			GASKET, AIR HORN	1		
3	10	33043	SCREW, AIR HORN TO FLOAT	7		
4	10	33048	SCREW, AIR HORN TO FLOAT	1		
5	13	26996	LOCKWASHER, AIR HORN SCRE	8		
6	1397	4337	NUT, FUEL INLET	1	SERIAL 03332138-03771644	
6	1397	3330	NUT, FUEL INLET	1	SERIAL 03771645-09999999	
7	35	53336	FILTER, FUEL INLET	1		
8	24	48143	SPRING, FUEL FILTER	1		
9			GASKET, FUEL INLET NUT	1		
10	1397	2060	FLOAT ASSEMBLY	1		
11		N.S.S.	PIN, HINGE - FLOAT TO AIR HOR	1		
12			INLET NEEDLE AND SEAT ASS	1		
13			GASKET, INLET NEEDLE AND	1		
14	1397	4258	FLOAT BOWL ASSEMBLY	1		
15		N.S.S.	VENTURI CLUSTER ASSEMBLY	1	SERIAL 03332138-03771644	
15		N.S.S.	VENTURI CLUSTER ASSEMBLY	1	SERIAL 03771645-09999999	
16			GASKET, VENTURI CLUSTER	1		
17		N.S.S.	SCREW, VENTURI CLUSTER T	1	ROCHESTER #7000294	
18		N.S.S.	GASKET, VENTURI CLUSTER E	1		
19		N.S.S.	SCREW, VENTURI CLUSTER T	2	ROCHESTER #7031949	
20	13	26995	LOCKWASHER, VENTURI CLU	2		
21			GUIDE, PUMP DISCHARGE - FL	1		
22			SPRING, PUMP DISCHARGE - F	1		
23			BALL, PUMP DISCHARGE - FLO	1		
24			POWER VALVE ASSEMBLY, FU	1		
25			GASKET, POWER VALVE	1		
26	1397	2447	JET, FLOAT BOWL (STANDARC	1		
27			STRAINER, PUMP INLET	1		
28	10	33047	SCREW, AIR HORN PUMP LEVI	1		
29		N.S.S.	PUMP SHAFT AND LEVER ASSE	1		
30		N.S.S.	ROD, PUMP (ROCHESTER #70	1		
31			CLIP, RETAINER - PUMP ROD	1		
32			PUMP ASSEMBLY, FLOAT BOW	1		
33			CLIP, RETAINER - FLOAT BOW	1		
34			SPRING, PUMP RETURN - FLO	1		
35			BALL, CHECK - PUMP INLET - F	1		
36			GASKET, THROTTLE BODY	1		
37	1397	2629	THROTTLE BODY ASSEMBLY	1		