



| Parts List | | | | | | |
|------------|-------|--------|--------------------------|-----|---------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | | 53113A | EXHAUST ELBOW ASSEMBLY | 1 | | |
| 2 | | 45798 | BRACKET, SUPPORT - WATER | 2 | | |
| 3 | 10 | 45813 | SCREW, SUPPORT BRACKET | 4 | | |
| 4 | 11 | 45812 | NUT, SUPPORT BRACKET SCR | 4 | | |
| 5 | | 53114 | EXHAUST ELBOWS, UPPER | 1 | | |
| 6 | 54 | 32739 | CLAMP, BELLOWS ATTACHING | 2 | | |
| 7 | 54 | 33683 | CLAMP, BELLOWS ATTACHING | 2 | | |
| 8 | | 45586 | WATER SHUTTER | 1 | | |
| 9 | 10 | 60992 | SCREW, EXHAUST ELBOW ATT | 3 | | |
| | 13 | 35048 | LOCKWASHER, EXHAUST ELBO | 3 | | |