



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
32		45490	GAUGE ASSEMBLY, OIL LEVEL (E	1		
33	32	37291	TUBE, OIL LEVEL GAUGE	1		
34		39332A 1	COVER ASSEMBLY, PUSH ROD	1		
35	10	39783	SCREW, PUSH ROD TO CYLIND	4		
36	27	34208	GASKET, PUSH ROD COVER	1		2
37	54	53883	CLIP, WIRING HARNESS TO PUS	1	SERIAL 03332138-03462607	
38	10	62568	SCREW, WIRING HARNESS CLIP	1	SERIAL 03332138-03462607	
39	12	20583	WASHER, HARNESS CLIP SCREW	1	SERIAL 03332138-03462607	
40		36405	OIL PUMP ASSEMBLY	1		
--	27	34460	GASKET, OIL PUMP COVER	1		
41	10	35339	SCREW, OIL PUMP TO CYLIND	2		
42		52146	SCREEN ASSEMBLY, OIL PUMP	1		
--	10	35366	SCREW, OIL PUMP SCREEN SUP	1		
--		60717	SUPPORT, OIL PUMP	1		
43		32720	CONNECTOR, OIL FILTER TO CY	1		
44		54111	OIL FILTER ASSEMBLY	1		
45		59341	COVER ASSEMBLY, CRANKCASE	1		
46	26	59342	OIL SEAL, CRANKCASE COVER	1		
47	27	49953	GASKET, CRANKCASE COVER	1		22
48	10	34277	SCREW, COVER TO CYLINDER B	8	SERIAL 03332138-03462607	
48	10	34277	SCREW, COVER TO CYLINDER B	7	SERIAL 03462608-03771645	
48	10	29179	SCREW, COVER TO CYLINDER B	1	SERIAL 03462608-03771644	
49		52583A 1	OIL PAN ASSEMBLY	1		
50	27	52144	GASKET SET, OIL PAN	1		
51	10	49950	SCREW, OIL PAN TO CYLINDER	12		
52	10	34500	SCREW, OIL PAN TO CYLINDER	6		
53	10	49956	SCREW, DRAIN - OIL PAN	1		
54	27	49955	GASKET, OIL PAN DRAIN SCREW	1		