



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		N.S.S.	ALTERNATOR ASSEMBLY, COMF	1		
1		N.S.S.	ALTERNATOR ASSEMBLY, COMF	.1		
1	11	33272	NUT, FAN AND PULLEY TO RO	1,1		
2	13	33309	LOCKWASHER, FAN AND PULL	1,1		
2A		90667	COLLAR, SHAFT - BETWEEN FA	.1		
3		38766	PULLEY, DRIVE END FRAME	1,		
3		90669	PULLEY, DRIVE END FRAME	.1		
4		33336	PAN, DRIVE END FRAME	1,1		
5		N.S.S.	COLLAR, DRIVE END FRAME - I	1,1		
6		56954	FRAME, DRIVE END	.1		
6		71704	FRAME, DRIVE END	1,		
7	30	56955	BALL BEARING, DRIVE END FR	1,		
7	30	90665	BALL BEARING, DRIVE END FR	.1		
8	12	56958	WASHER, GREASE SLINGER -	1,		
9		56956	PLATE, BALL BEARING RETAIN	1,1		
10	10	27304	SCREW, RETAINER PLATE TO	3,		
10	10	38028	SCREW, RETAINER PLATE TO	.3		
11	10	35208	LOCKWASHER, RETAINER PLA	3,		
12		N.S.S.	COLLAR, DRIVE END FRAME - I	.1		
14		60694	SCREEN, DRIVE END FRAME	1,		
14		90668	SCREEN, DRIVE END FRAME	.1		
15		56935	STATOR ASSEMBLY	1,1		
16	54	33329	CLIP, TERMINAL - STATOR LE	3,		
17		56934	ROTOR	1,1		
18		56939	RECTIFIER BRIDGE	1,1		
19	10	71702	SCREW, RECTIFIER BRIDGE A	1,1		
20	13	34383	LOCKERWASHER, RECTIFIER I	1,		
22		56938	DIODE TRIO	1,1		
23	13	34383	LOCKWASHER, DIODE TRIO TI	3,		
24	11	21923	NUT, DIODE TRIO TO RECTIFIE	3,3		
25	10	71703	SCREW, BRUSH HOLDER ATT	1,1		
26	13	34383	LOCKWASHER, GROUND BRU	1,		
27		60692	TERMINAL PACKAGE, BATTERY	1,1		
28	12	56947	WASHER, SPONGE NEOPRENE	1,1		
29		58296	CONDENSER	1,1		
30	393	2730	BRACKET, CONDENSER	1,1		
31	10	60693	SCREW, CONDENSER ATTACH	1,1		
32	10	60693	SCREW, CONDENSER LEAD TE	1,1		
34		56942	HOLDER AND BRUSH ASSEMB	1,1		
35	24	56943	SPRING, TENSION - BRUSHE	2,2		
36	10	60691	SCREW, BRUSH HOLDER ATT	2,2		