



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	50	69863A 1	STARTER MOTOR ASSEMBLY (D	OPT		
1	50	79821A 2	STARTER MOTOR ASSEMBLY (D	OPT		
2	10	94435	BOLT, STARTER MOTOR MOUN	1		
3	10	34544	BOLT, STARTER MOTOR MOUN	1		
4		54671	BRACE, STARTER MOTOR	1	USE WITH B-50-69863A1 START	
5	16	52387	STUD, BRACE TO MOTOR AND C	2	USE WITH B-50-69863A1 START	
6	11	64809	NUT, BRACE STUD	2	USE WITH B-50-69863A1 START	
7		87300	BRACKET, STARTER MOTOR	1	USE WITH B-50-79821A2 START	
8	10	26487	SCREW, STARTER MOTOR BRAI	1	USE WITH B-50-79821A2 START	
9	13	35048	LOCKWASHER, BRACKET SCREW	1	USE WITH B-50-79821A2 START	
10	12	55149	WASHER, STARTER MOTOR BR.	1	USE WITH B-50-79821A2 START	
11	11	32219	NUT, SOLENOID SWITCH TERMI	OPT		
11	11	40020 4	NUT, SOLENOID SWITCH TERMI	OPT		
12	11	26419	NUT, SOLENOID SWITCH TERMI	1		
13	13	26995	LOCKWASHER, SOLENOID SWIT	2		
14	13	26996	LOCKWASHER, STARTER MOTO	1	USE WITH B-50-69863A1 STAR	
15	11	68219	NUT, STARTER MOTOR TERMIN	1	USE WITH B-50-69863A1 STAR	
14	12	27985	WASHER, STARTER MOTOR TER	1	USE WITH B-50-79821A2 START	
15	11	68219	NUT, STARTER MOTOR TERMIN	1	USE WITH B-50-79821A2 START	
16		78403A 2	ALTERNATOR ASSEMBLY	1		
17		58333	BRACE, ALTERNATOR TO EXHA	1		
18	16	54177	STUD, ALTERNATOR BRACE TO	1		
19	12	20553	WASHER, ALTERNATOR BRACE	1		
20	11	23161	NUT, ALTERNATOR BRACE STU	1		
21	10	29198	SCREW, ALTERNATOR BRACE T	1		
22	12	26168	WASHER, ALTERNATOR BRACE	1		
23	10	37626	SCREW, ALTERNATOR TO BRAC	1		
24	23	63894	SPACER, ALTERNATOR TO BRAI	1		
25	12	25970	WASHER, ALTERNATOR TO BRA	2		
26	11	23161	NUT, ALTERNATOR SCREW	1		
27	16	56826	STUD, ALTERNATOR BRK. (1 1/2	2		
28		63857A 1	BRACKET ASSEMBLY, ALTERNA	1		
29	12	20553	WASHER, MOUNTING BRACKET	2		
30	11	23161	NUT, MOUNTING BRACKET STU	2		
30A	12	96457	WASHER, BOOT ATTACHING (P	1		
31	13	26992	LOCKWASHER, ALTERNATOR TI	1		
32	11	20890	NUT, ALTERNATOR TERMINAL	1		
33	84	78581A 3	WIRING HARNESS ASSEMBLY, A	1	USE WITH B-84-66962A2 WIRIN	
34	88	79023A90	FUSE ASSEMBLY, SOLENOID - 90	1	USE WITH B-84-66962A2 WIRIN	
35	85	79695	BOOT, INSULATOR	1	USE WITH B-84-66962A2 WIRIN	
36	12	26992	LOCKWASHER, SOLENOID ATTA	1	USE WITH B-84-66962A2 WIRIN	