



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		90507A12	PUMP ASSEMBLY, PWDER STEE	1		
2	36	95805	CAP, POWER STEERING PUMP	1		
3		73873A 1	PULLEY, POWER STEERING PI	1		
3A	16	41877	STUD, POWER STEERING PUM	1		
4	57	65607T	V-BELT, POWER STEERING PUM	1		
5	32	96790	HOSE, PRESSURE (FITTINGS ON	1		
6	25	89879	"O" RING, PRESSURE HOSE	1		
7	32	98843 39	HOSE, RETURN (FITTINGS ON O	1		
8	32	52519 14	HOSE, PUMP TO OIL COOLER	1		
9	54	35830	CLAMP, HOSE ATTACHING	3		
10	54	92850	CLAMP, POWER STEERING HOS	1		
11		96772A 1	BRACE, POWER STEERING PUM	1		
13		96872A 2	BRACKET, POWER STEERING PI	1		
14	10	76926	SCREW, BRACE TO BRACKET	1		
15	12	34714	WASHER, BRACE SCREW	1		
16	10	40001192	SCREW, POWER STEERING PUM	3		
16	10	40001195	SCREW, POWER STEERING PUM	1		
17	23	90520	SPACER, PUMP MOUNTING SCR	2		
18	23	72057	SPACER, PUMP MOUNTING SCR	2		
19	23	96818	BUSHING, PUMP MOUNTING, SC	1		
20		65606T	BRACKET, MOUNTING	1		
21		77054	STAY STRAP, POWER STEERING	1		