



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	84	98422A 4	WIRING HARNESS (SHIFT COMP)	1		2
1	84	98422A10	WIRING HARNESS (SHIFT COMP)	1		2
1	84	98422A11	WIRING HARNESS (DIGITAL IGN)	1		
2		26079	PLATE, WIRING HARNESS - MET	1		
3	10	34696	SCREW, PLATE - METAL	4		
2		26079A 2	PLATE ASSEMBLY, WIRING HAR	1		
3	10	15001	SCREW, PLATE - PLASTIC	4		
4		98428A 2	BRACKET, MOUNTING (CONVEN	1		
4A		19427T	BRACKET, MOUNTING (DIGITAL	1		
5		97257A 1	WATER TEMPERATURE SENDE	1		
5		49734A 1	WATER TEMPERATURE SENDE	OPT		
6	13	26996	LOCKWASHER, WATER TEMPE	1		
7	11	68219	NUT, WATER TEMPERATURE	1		
8		90806	OIL PRESSURE SENDER ASSEM	1		
8		37293	OIL PRESSURE SENDER ASSEM	OPT		
9	13	26996	LOCKWASHER, OIL PRESSURE	1		
10	11	68219	NUT, OIL PRESSURE SENDER	1		
11	22	32974	ADAPTOR, OIL PRESSURE SENC	1		
12	88	11178	CIRCUIT BREAKER (50 AMP)	AR		
12	88	93582	CIRCUIT BREAKER (60 AMP)	AR		
13	13	26996	LOCKWASHER, CIRCUIT BREAK	2		
14	11	68219	NUT, CIRCUIT BREAKER TERMIN	2		
15	10	45862	SCREW, CIRCUIT BREAKER (7/8	2		
16	11	46438	NUT, INSULATOR SCREW	2		
17	89	96158	STARTER SOLENOID	1		
18	10	98256	SCREW, STARTER SOLENOID	2		
19	11	20586	NUT, STARTER COLENOID SCRE	2		
20	13	26992	LOCKWASHER, STARTER SOLE	2		
21	11	26419	NUT, STARTER SOLENOID TERM	2		
22	11	94330	NUT, STARTER SOLENOID TERM	2		
23		45315	TERMINAL BLOCK	1	- USE WITH RING TERMINALS	
24	10	62568	SCREW, TERMINAL BLOCK (3/8"	1	- USE WITH RING TERMINALS	
24	10	35519	SCREW, TERMINAL BLOCK (1/2"	1	- USE WITH RING TERMINALS	
25	84	94227A 2	RESISTANCE CABLE KIT (TO REF	1		
-	84	11149A 5	ADAPTOR KIT	1	THIS KIT IS USED TO ADAPT "F	