



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		32682A	2 BODY ASSEMBLY, RELIEF VALVE	1,1,,		
1		35143A	1 BODY ASSEMBLY, REILEF VALVE	,,1,1		
2		32729A	1 CAP ASSEMBLY, RTRELIEF VAL	1,1,1,1		
3	27	32019	GASKET, RELIEF VALVE BODY	1,1,1,1		
4	24	35087A	1 SPRING ASSEMBLY, RELIEF VA	1,1,1,1		
5		35086	BUTTON, CHACK VALVE - RE	1,1,1,1		
6	22	32802	PLUG, PIPE - RELIEF VALVE E	1,1,,		
7	27	32811	GASKET, RELIEF VALVE BODY	1,1,,		
7	27	35144	GASKET, RELIEF VALVE BODY	,,1,1		
8	10	34634	SCREW, RELIEF VALVE BODY TO	,,7,7,		
8	10	35388	SCREW, RELIEF VALVE BODY TO	,,7,7,		
9	13	26992	LOCKWASHER, RELIF VALVE BO	,,7,7,		
10		27711	RETAINER, RELIEF VALVE BODY	1,1,,		
10		26551	RETAINER, RELIEF VALVE BODY	,,1,1		
11	32	33116	HOSE, DRAIN - RELIEF VALVE BC	1,1,1,1		
12	54	32779	CLAMP, DRAIN HOSE TO RELIEF	2,2,2,2		
13	22	32715	ELBOW, DRAIN HOSE - EXHAUS	1,1,1,1		
14		32724	ELBOW, EXHAUST - THERMOST.	1,1,,		
14		35148	ELBOW, EXHAUST - THERMOST.	,,1,1		
15	22	32803	PLUG, PIPE - EXHAUST ELBOW	1,1,1,1		
16		32723	CONTAINER, THERMOSTAT - MA	1,1,,		
16		35145	CONTAINER, THERMOSTAT - MA	,,1,1		
17	27	32812	GASKET, THERMOSTAT CONTAI	1,1,,		
17	27	35146	GASKET, THERMOSTAT CONTAI	,,1,1		
18	10	34634	SCREW, THERMOSTAT CONTAIN	,,5,5,		
18	10	35388	SCREW, THERMOSTAT CONTAIN	,,5,5,		
19	13	26992	LOCKWASHER, THERMOSTAT C	,,5,5,,		
20		35884	THERMOSTAT	1,1,1,1		
21	27	32813	GASKET, EXHAUST ELBOW	1,1,,		
21	27	35147	GASKET, EXHAUST ELBOW	,,1,1		
22	10	22421	SCREW, EXHAUST ELBOW TO T	4,4,,		
22	10	35156	SCREW, EXHAUST ELBOW TO T	,,4,4		
23	11	24652	NUT, EXHAUST ELBOW TO THE	4,4,4,4		
24	10	28667	SCREW, EXHAUST ELBOW TO T	1,1,,		
24	10	35388	SCREW, EXHAUST ELBOW TO T	,,1,1		
25	22	20445	NIPPLE, BLEED HOSE TO RELIEF	1,1,,		
25	22	33060	NIPPLE, BLEED HOSE TO THER	,,1,1,1		
27	12	21631	WASHER, REMOTE CONTROL C	2,2,2,2		
28	23	31866	SPACER, REMOTE CONTROL CO	1,1,1,1		
29	11	20586	NUT, REMOTE CONTROL CABLE	1,1,1,1		