



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		32785	WIRING HARNESS, EXTERNAL	1,...		
1		34424	WIRING HARNESS, EXTERNAL	,1,1,1		
2	54	22875	CLIP, WIRING HARNESS TO BOA	2,...		
2	54	22627	CLIP, WIRING HARNESS TO BOA	2,2,2		
3	10	22793	SCREW, WOOD-WIRING HARNE	2,2,2,2		
4		22789	"D" WASHER, WIRING HARNESS	2,2,2,2		
5		32702	VOLTAGE REGULATOR	1,...		
5		34141	VOLTAGE REGULATOR	,1,1,1		
7	10	29238	SCREW, VOLTAGE REGULATOR	3,3,3,3		
8	10	33615	SCREW, VOLTAGE REGULATOR	2,2,2,2		
9	12	22887	WASHER, VOLTAGE REGULATOR	4,4,4,4		
10	23	28626	SPACER, VOLTAGE REGULATOR	2,2,2,2		
12	50	32703	STARTER MOTOR ASSEMBLY C	1,1,1,1		
13	23	34547	SPACER, STARTER MOTOR	1,...		
14	10	34545	BOLT, STARTER MOTOR MOUNT	1,1,1,1		
15	10	34544	BOLT, STARTER MOTOR MOUNT	1,1,1,1		
16	12	32648	WASHER, STARTER MOTOR BO	1,1,1,1		
17		32786	TAB, STARTER MOTOR SOLENO	1,1,1,1		
18	10	20191	SCREW, WIRING HARNESS LEA	1,1,1,1		
19	13	26995	LOCKWASHER, WIRING HARNE	1,1,1,1		
20	11	26419	NUT, WIRING HARNESS LEAD S	1,1,1,1		
21		34546	BRACE, STARTER MOTOR	1,1,1,1		
22	10	35192	SCREW, BRACE TO STARTER M	2,2,...		
22	10	35765	SCREW, BRACE TO STARTER M	,,2,2		
23		32786	TAB, WIRING HARNESS LEAD T	1,1,1,1		
24	10	20191	SCREW, WIRING HARNESS LEA	1,1,1,1		
24	10	20191	SCREW, WIRING HARNESS LEA	11,11,1		
25	13	26995	LOCKWASHER, WIRING HARNE	1,1,1,1		
26	11	26419	NUT, WIRING HARNESS LEAD S	1,1,1,1		
27	11	28517	NUT, SOLENOID SWITCH TRMI	1,1,1,1		
28	11	26419	NUT, SOLENOID SWITCH TERMI	1,1,1,1		
29		32786	TAB, STARTER MOTOR TO CYLI	1,1,1,1		
30	54	26550	CLIP, WIRING HARNESS TO STA	1,...		
30	54	22875	CLIP, WIRING HARNESS TO STA	,1,1,1		
31	10	20191	SCREW, WIRING HARNESS CLIF	1,1,1,1		
32	13	26995	LOCKWASHER, WIRING HARNE	1,1,1,1		
33		22789	"D" WASHER, WIRING HARNESS	1,1,1,1		
34	11	26419	NUT, WIRING HARNESS CLIP SC	1,1,1,1		
35		32828	WATER TEMPERATURE SENDEL	1,...		
35		34625	WATER TEMPERATURE SENDEL	,1,1,1		
36	12	26995	LOCKWASHER, WATER TEMPE	1,1,1,1		