



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		33483	ELBOW, WATER OUTLET - CYLIN	1	SERIAL 00000000-01823075	
2	32	33485	HOSE, WATER OUTLET ELBOV	1	SERIAL 00000000-01823075	
1A		38057	ELBOW, WATER OUTLET - CYLIN	1	SERIAL 01823076-09999999	
2A	32	38066	HOSE, WATER OUTLET ELBOV	1	SERIAL 01823076-09999999	
3	54	32780	CLAMP, HOSE TO WATER OUTLI	2		
4	27	33680	GASKET, WATER OUTLET ELBO	1		
5	10	21077	SCREW, WATER OUTLET ELBO	2		
6	22	32804	PLUG, PIPE - WATER OUTLET EL	1		
7	22	33060	NIPPLE, BLEED HOSE TO WATEI	1		
8		36112	BODY, EXHAUST MANIFOLD	1		
9	22	37372	PLUG, PIPE - EXHAUST MANIFOL	2		
10	54	22627	CLAMP, WIRING HARNESS TO E	1		
11	10	29240	SCREW, WIRING HARNESS CLAI	1		
12		22789	"D" WASHER, WIRING HARNESS	1		
13	22	32802	PLUG, PIPE - EXHAUST MANIFOL	1		
14	16	35897	TITLE LEVER TO EXHAUST MANI	1		
15	12	21631	WASHER, THROTTLE LEVER ST	2		
16	23	32796	BUSHUNG, THROTTLE LEVER S	1		
17	11	20586	NUT, THROTTLE LEVER STUD L	1		
18		35893	ELBOW, WATER OUTLET - EXHA	1		
19	27	35895	GASKET, WATER OUTLET ELBO	1		
20	10	35388	SCREW, WATER OUTLET ELBO	6		
21		26551	RETAINER, WATER OUTLET ELE	1		2
22	32	33484	HOSE, WATER OUTLET ELBOV	1		
23	54	32781	CLAMP, HOSE TO WATER OUTLI	2		
24		32877	COVER, WATER PUMP	1		
25	54	38426	CLAMP, WATER PUMP COVER T	1		
26	10	25299	SCREW, WATER PUMP FLANGE	1		
27	22	36382	PLUG, PIPE - EXHAUST MANIFOL	1		
28	16	34612	STUD, EXHAUST MANIFOLD BO	6		
29	10	21077	SCREW, EXHAUST MANIFOLD BI	1		
29	10	26632	SCREW, EXHAUST MANIFOLD BI	1		
30	13	37459	LOCKWASHER, EXHAUST MANIF	8		
31	12	20553	WASHER, EXHAUST MANIFOLD	8		
32	11	20087	NUT, EXHAUST MANIFOLD BO	6		
33		36113	COVER, INTAKE MANIFOLD	1		2
34	27	36114	GASKET, INTAKE MANIFOLD COV	1		2
35	10	35390	SCREW, INTAKE MANIFOLD COV	8		2
36	10	35388	SCREW, INTAKE MANIFOLD COV	10		2
33		38981	COVER, INTAKE MANIFOLD - NO	1		1
34	27	28255	GASKET, INTAKE MANIFOLD COV	1		1