



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		45514A	GIMBAL HOUSING ASSEMBLY (S)	1		
1		45637A	GIMBAL HOUSING ASSEMBLY (P)	1		
1		45702A	GIMBAL HOUSING ASSEMBLY (P)	1		
2	16	37270	STUD, GIMBAL HOUSING TO T	2		
3	31	32536	BEARING, ROLLER - GIMBAL H	1		
4	26	32911	OIL SEAL, LOWER GIMBAL HO	2		
5	23	38634	BUSHING, SYNTHANE - GIMBA	1		
6	26	32540	OIL SEAL, UPPER GIMBAL HO	1		
7	22	21290	PLUG, PIPE - GIMBAL HOUSIN	1		
8	22	31345	FITTING, GREASE - GIMBAL HC	1		
9		29359	LUBRICAP, GIMBAL HOUSING	1		
10	26	36143	SEAL, GREASE - GIMBAL HOUS	1		
11	23	35130	ADAPTOR, BEARING CARRIER	1		
12	30	36418	BEARING, BALL - GIMBAL HOUS	1		
13	53	35128	RING, RETAINING - BEARING C	1		
14	15	35244A	SHIM, GIMBAL HOUSING BEAR	AR		
15	10	25612	SCREW, DRIVE-GIMBAL HOUSI	13		
16	25	20863	"O" RING, GIMBAL HOUSING	1		
--		46443	EMBLEM, GIMBAL HOUSING	1		
17		34762A	PLATE ASSEMBLY, INHIBITOR -	1		
18	10	34763	SCREW, INHIBITOR PLATE TO	2		
19	17	45212	PIN, SWIVEL - GIMBAL HOUSING	1		
20	18	34159	COTTER PIN, RETAINING - LOWE	1		
21	12	32518	WASHER, GIMBAL HOUSING TO	1		
22	10	35624	BOLT, GIMBAL HOUSING TO TR	2		
23	12	32620	WASHER, GIMBAL HOUSING BOI	2		
24		31659	BELLOWS, SHIFT ACTUATING CA	1		
25	54	38863	CLAMP, ACTUATING CABLE BELL	1		
26	54	31766	CLAMP, SHIFT ACTUATING CABL	1		
27	12	22248	WASHER, GIMBAL HOUSING STI	2		
28	11	34933	NUT, GIMBAL HOUSING STUD	2		
29	32	32631	TUBE, WATER - GIMBAL HOUSIN	1		
30	23	28055	BUSHING, RUBBER - WATER TU	1		
31		32517	COVER, WATER TUBE SEALING	1		
32	10	28635	SCREW, WATER TUBE SEALING	2		
33		45530A	ELBOW ASSEMBLY, EXHAUST (R	1		
33		53272A	ELBOW ASSEMBLY, EXHAUST (R	1		
33		53113A	ELBOW ASSEMBLY, EXHAUST (R	1		
34		45798	BRACKET, SUPPORT - WATER	(1) 2		
35	10	45813	SCREW, SUPPORT BRACKET	(2) 4		
36	11	45912	NUT, SUPPORT BRACKET SCR	(2) 4		