



Parts List					Qty	Comment	Footnote
Ref	Class	Part	Description				
1	32	52951A 1	HOSE, HYDRAULIC PUMP TO RE	1,			
1	32	45720	HOSE, HYDRAULIC PUMP TO RE	,1,1			
2	32	45669	HOSE, LIFT - HYDRAULIC PUMP	1,1,1			
3	54	45806	CLAMP, HYDRAULIC HOSE TO TI	1,1,1			
4	10	35519	SCREW, HYDRAULIC HOSE CLA	1,1,1			
5	32	45705	HOSE, TRIM - VALVE TO GIMBAL	1,			
5	32	48076	HOSE, TRIM - VALVE TO GIMBAL	,1,1			
6	22	36033	CONNECTOR, GIMBAL HOUSING	2,2,2			
7	27	36043	GASKET, GIMBAL HOUSING CON	2,2,2			
8	11	36084	NUT, GIMBAL HOUSING CONNEC	2,2,2			
9	32	45704	HOSE, HYDRAULIC TRIM-GIMBAL	1,1,1			
10	32	45973	HOSE, HYDRAULIC - GIMBAL HO	1,1,1			
11		45519	COVER, HYDRAULIC HOSES TO	2,2,2	NOT AS SHOWN		
12	10	36070	SCREW, COVER TO GIMBAL HOU	4,4,4			
13	32	45703	HOSE, HYDRAULIC TRIM - GIMB	1,1,1			
14	32	45974	HOSE, HYDRAULIC - GIMBAL HO	1,1,1			
15		45706A 1	TILT CYLINDER ASSEMBLY, CON	2,2,2			
16	17	45735	PIN FRONT ANCHOR - TILT CYLI	1,1,1			
17	12	45737	WASHER, FRONT ANCHOR PIN	2,2,2			
18	23	45736	BUSHING, RUBBER - FRONT ANCH	4,4,4			
19	24	46312	SPRING, FRONT ANCHOR PIN	2,2,2			
20	12	46765	WASHER, FRONT ANCHOR PIN	2,2,2			
21	11	34932	NUT, FRONT ANCHOR PIN	2,2,2			
22	17	45738	PIN, REAR ANCHOR-TILT CYLINE	1,1,1			
23	12	45737	WASHER, REAR ANCHOR PIN	2,2,2			
24	23	45736	BUSHING, RUBBER - REAR ANCH	4,4,4			
25	24	46312	SPRING, REAR ANCHOR PIN	2,2,2			
26	12	46765	WASHER, REAR ANCHOR PIN	2,2,2			
27	11	34932	NUT, REAR ANCHOR PIN	2,2,2			