



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		39922	BODY, EXHAUST MANIFOLD	1	
2	10	21077	SCREW, EXHAUST MANIFOLD B	1	
2	10	26632	SCREW, EXHAUST MANIFOLD BI	1	
3	16	34612	STUD, EXHAUST MANIFOLD BO	4	
4	12	20553	WASHER, EXHAUST MANIFOLD	8	
5	13	37459	LOCKWASHER, EXHAUST MANIF	8	
6	11	20087	NUT, EXHAUST MANIFOLD BOD	6	
7		39916	END CAP, EXHAUST MANIFOLD I	1	
8	27	39923	GASKET, END CAP	1	
9	10	35388	SCREW, ENDF CAP TO EXHAUS	4	
10	22	32802	PLUG, PIPE - EXHAUST MANIFOL	1	
11	54	28938	CLAMP, WIRING HARNESS TO E	1	
12	10	20031	SCREW, WIRING HARNESS CLAI	1	
13	13	26992	LOCKWASHERE, WIRING HARNE	1	
14	32	45042	HOSE, INLET - WATER DISBRIBI	1	
15	54	32779	CLAMP, INLET HOSE TO WATER	2	
16	22	37372	PLUG, EXHAUST MANIFOLD BO	2	
17	54	22740	CLAMP, WIRING HARNESS TO	1	
18	10	22028	SCREW, WIRING HARNESS CLAI	1	
19	13	26996	LOCKWASHER, WIRING HARNE	1	
20		22789	"D" WASHER, WIRING HARNE	1	
21	10	25299	SCREW, WATER PUMP FLANGE	1	
22		39921	BLOCK, WATER DISBRIBUTION	1	
23	22	32715	ELBOW, WATER DISBRIBUTION	1	
24	10	39970	SCREW, WATER DISBRIBUTION	2	BODY (7/8")
24	10	45474	SCREW, WATER DISBRIBUTION	4	BODY (1 1/2")
25	27	39917	GASKET, WATER DISTRIBUTION	1	
26		35884	THERMOSTAT	1	
27		39918	CONTAINER, THERMOSTAT	1	
28	27	39914	GASKET, THERMOSTAT CONTAI	1	
29	10	35388	SCREW, THERMOSTAT CONTAI	4	(1")
29	10	35390	SCREW, THERMOSTAT CONTAI	2	(1 3/4")
30		26551	RETAINER, THERMOSTAT HOUS	1	
31	32	33484	HOSE, WATER DISTRIBUTION B	1	
32	54	32781	CLAMP, HOSE TO WATER DISTF	2	
33		32877	COVER, WATER PUMP	1	
34	54	38426	CLAMP, WATER PUMP COVER T	1	
35		39919	ELBOW, WATER OUTLET - CYLIN	1	
36	10	21077	SCREW, WATER OUTLET ELBO	2	
37	27	33680	GASKET, WATER OUTLET ELBO	1	
38	22	32802	PLUG, PIPE, WATER OUTLET EL	1	