



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		46734A	BELL HOUSING ASSEMBLY	1	SERIAL 00000000-33443920	
1		63505A	BELL HOUSING ASSEMBLY	1	SERIAL 03469428-03780849	
1		66156A	BELL HOUSING ASSEMBLY(WITH	1		
1		65535A	BELL HOUSING ASSEMBLY(WITH	1		
2	27	64818	GASKET,DRIVE SHAFT HSG.TC	1		
3	22	33066	CONNECTOR,WATER HOSE TC	1		
4	22	32125	CONNECTOR,SHIFT CABLE-BEI	1		
5	10	25612	SCREW,DRIVE-BELL HOUSING	8		
6		31014	BUMPER,BELL HOUSING	1	SERIAL 00000000-33443920	
6		63679	BUMPER,BELL HOUSING	1	SERIAL 03469428-09999999	
7		35088	BUSHING,BELL HOUSING(5/8"	1		
8	26	45587	OIL SEAL,BELL HOUSING	1		
9	23	45588	BUSHING,BELL HOUSING(5/1	1		
10	27	35982	GASKET,RUBBER-BELL HOUSI	1		
11	25	33504	"O" RING,BELL HOUSING	1		
12	12	38000	WASHER,SYNTHANE-BELL HO	2		
12	12	72498	WASHER,SYNTHANE-BELL HO	2		
13	16	59579	STUD,BELL HOUSING TO DRIV	6		
14	12	35935	WASHER,BELL HOUSING STUD	6		
15	11	34933	NUT,BELL HOUSING STUD	6		
16	10	36398	SCREW,PLUG-BELL HOUSING(1/	2		
17	22	31345	FITTING,GREASE-BELL HOUSING	2		
18		29359	LUBRICAP,BELL HOUSING GREA	2		
19		36223A	BELLOWS ASSEMBLY,UNIVERSA	1	SERIAL 00000000-33443920	
19		60932A	BELLOWS ASSEMBLY,UNIVERSA	1	SERIAL 03469428-09999999	
20	54	31765	CLAMP,UNIVERSAL JOINT BELL	2		
21	32	47642	HOSE,WATER-BELL HOUSING TI	1		
22	54	32523	CLAMP,WATER HOSE ATTACHIN	2		
23		32734	BELLOWS,EXHAUST-BELL HOUS	1		
24	54	32533	CLAMP,EXHAUST BELLOWS TO	2		
25		45589A	SHAFT ASSEMBLY,SHIFT-UPPEF	1		
26		32628	SHAFT,SHIFT-INTERMEDIATE	1	SERIAL 00000000-04179999	
26		62104	SHAFT,SHIFT-INTERMEDIATE	1	SERIAL 04180000-09999999	
27	18	32665	COTTER PIN,INTERMEDIATE SH	1		
28	12	32666	WASHER,INTERMEDIATE SHIFT	1		
29		45518A	LEVER ASSEMBLY,UPPER SHIFT	1		
30	12	39116	WASHER,UPPER SHIFT LEVER	1		
31	10	45590	SCREW,UPPER SHIFT LEVER TC	1		