



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		65059A 1	FLYWHEEL HOUSING ASSEMBLY	1		
2	23	46742	SPACER, FLYWHEEL HOUSING	2		
3		35864	COVER PLATE, FLYWHEEL HO	1		
4	10	47277	SCREW, COVER PLATE TO FLY	6		
4	10	26065	SCREW, SHIFT CLIP AND PLAT	1		
5	11	29250	NUT, COVER PLATE SCREW	6		
6	54	61001	"J"CLIP, STERN DRIVE SHIFT CA	1		
7	54	72531	EYE, LIFTING - FLYWHEEL HO	1		
8	10	26632	SCREW, FLYWHEEL HOUSING T	5		
9	10	45754	SCREW, BRACKET AND FLYWHE	1		
10	13	37459	LOCKWASHER, BRACKET AND F	6		
11	12	20553	WASHER, BRACKET AND FLYW	1		
12	11	32219	NUT, BRACKET AND FLYWHEEL	1		
13		33149	MOUNT, FLYWHEEL HOUSING	2		
14		67850	EYE, LIFTING - CYLINDER BLOCK	1		
15	10	34353	SCREW, LIFTING EYE TO CYLIN	1		
16	13	37459	LOCKWASHER, LIFTING EYE TO	1		
17		73571A 2	BRACKET ASSEMBLY, FRONT MI	1		
18	23	35903	SPACER, FRONT MOUNTING B	1		
19		32833	MOUNT, FRONT MOUNTING BF	1		
20		35862	BLOCK, SPACER - FRONT MOUN	1		
21	10	32557	SCREW, BRACKET AND SPACER	2		
22	13	32993	LOCKWASHER, BRACKET AND S	2		
23	12	22248	WASHER, BRACKET AND SPACE	2		
24	10	26486	SCREW, FRONT MOUNTING BR/	2		
25	13	37459	LOCKWASHER, FRONT MOUNTII	2		
26	12	34931	WASHER, FRONT MOUNTING BF	2		
27	16	36100	STUD, ADJUSTING-FRONT MOU	1		
28	12	36103	WASHER, FRONT MOUNTING BF	2		
29	12	32638	WASHER, FRONT MOUNTING BF	1		
30	12	20959	WASHER, FRONT MOUNTING BF	1		
31	23	36101	SPACER, FRONT MOUNTING BR.	1		
32	12	36104	WASHER, RUBBER - FRONT MOI	1		
33	11	20220	NUT, FRONT MOUNTING BRACK	1		
34	11	32882	NUT, FRONT MOUNTING BRACK	2		
35		32778	SUPPORT, FRONT - ENGINE MOI	1		
36		32849	SUPPORT, FRONT - ENGINE MOI	OPT.		
37	11	47525	NUT, JAM - FRONT MOUNTING B	1		
38		45915	TERMINAL BLOCK	1		
39	10	20189	SCREW, TERMINAL BLOCK TO F	1		
40	11	22164	NUT, TERMINAL BLOCK SCREW	1		