



CYLINDER HEAD AND ROCKER COVER

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		14252	ROCKER COVER (RIGHT)	1		
1		14251	ROCKER COVER (LEFT) - CLAMP	1		
2		17345	CAP, OIL FILLER - CLAMP TYPE I	1		
1		814504	ROCKER COVER (LEFT) - SCREW	1		
2	36	18710	CAP, OIL FILLER - SCREW TYPE	1		
3	10	17344	SCREW, ROCKER COVER	6		
5		17339	ROD, VALVE PUSH (DOUBLE BAL	12		
6		85803	VALVE, EXHAUST (STANDARD)	6		
6		49076	VALVE, EXHAUST (.015 O.S.)	AR		
7		97661	VALVE, INLET (STANDARD)	6		
7		97662	VALVE, INLET (.015 O.S.)	AR		
8	26	34217	SEAL, VALVE (INLET AND EXHAL	12		2
8	26	97664	SEAL, VALVE (INLET)	6		2
9	24	48347	SPRING, VALVE (INLET AND EXP	12		
10		34518	SHIELD, VALVE SPRING CAP	12		
11		48348	CAP, INLET VALVE	6		
12		11965	ROTATOR, VALVE SPRING - EXH	6		
13	28	54797	KEY, VALVE STEM	24		
14		35329	ARM, ROCKER VALVE	12		
15		35331	BALL UNIT, ROCKER VALVE ARM	12		
16	11	34516	NUT, ROCKER VALVE ARM STUC	12		
17	938	9427	CYLINDER HEAD ASSEMBLY	2		
18	16	34522	STUD, ROCKER VALVE ARM (C	AR		
18	16	34521	STUD, ROCKER VALVE ARM (C	AR		
19	27	816460	GASKET, CYLINDER HEAD	2		2
20	10	11968	BOLT, CYLINDER HEAD TO CYLII	12		
21	10	11967	BOLT, CYLINDER HEAD TO CYLII	4		
22	10	11966	BOLT, CYLINDER HEAD TO CYLII	10		
23	27	11988	GASKET, ROCKER COVER	2		2
-	27	11977A92	ENGINE GASKET SET	1		