



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	32	44348	TUBE, EXHAUST	2		
2	54	31765	CLAMP, EXHAUST BELLOWS	8		
3		14478T	EXHAUST ELBOW ASSEMBLY	2		
4	54	31765	CLAMP, EXHAUST TUBE	8		
5	32	14358	EXHAUST TUBE	2		
6		14348A	WATER SHUTTER	1		
7		44266T	EXHAUST PIPE	1		
8	10	58640	SCREW, EXHAUST ELBOW (1-1/4	4		
9	13	41471	LOCKWASHER, EXHAUST ELBO\	4		