



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		11974	INTAKE MANIFOLD (175 - 4.3L)	1		
1		42752	INTAKE MANIFOLD (205 - 4.3L/LX)	1		
2	10	11976	BOLT, INTAKE MANIFOLD	8		
2	10	11975	BOLT, INTAKE MANIFOLD	4		
3	22	75983	PLUG, VACUUM HOLE	1		
4		42453	BRACKET, LIFTING (FRONT)	1		
4		42745	BRACKET, LIFTING (REAR)	1		
5	10	34354	SCREW, LIFTING BRACKET (1-1/2")	1		
6		N.S.S.	STUD, GUARD TO INTAKE MANIFOLD	4		
7		42753	GUARD, INTAKE MANIFOLD	1		
8	27	11977	GASKET SET, INTAKE MANIFOLD	1		2
9		17437	WATER PUMP ASSEMBLY	1		
10	27	34897	GASKET, WATER PUMP MOUNT	2		2
11	22	48336	PLUG, WATER PUMP	1		
12	10	32132	SCREW, WATER PUMP TO CYLINDER	1		
12	10	47688	SCREW, WATER PUMP TO CYLINDER	1		
12	10	52200	SCREW, WATER PUMP TO CYLINDER	1		
12		N.S.S.	STUD, WATER PUMP TO CYLINDER	1		
13		15120T	PULLEY, WATER PUMP (5-1/2" DIA.)	1		
13		19692T	PULLEY, WATER PUMP (7" DIA.)	1		
14	10	47277	SCREW, PULLEY TO WATER PUMP	4		
15	13	39107	LOCKWASHER, WATER PUMP PULLEY	4		
16		11990	BALANCER, CRANKSHAFT	1		
17		90081T	PULLEY, HARMONIC BALANCER	1		
18	57	49213A	BELT (44") (USE WITH 5-1/2" DIA. PULLEY)	1		
18	57	48120A	BELT (46") (USE WITH 7" DIA. PULLEY)	1		
19	10	32515	BOLT, PULLEY AND HARMONIC BALANCER	1		
20	13	39131	LOCKWASHER, PULLEY AND HARMONIC BALANCER	1		
21	12	35332	WASHER, PULLEY AND HARMONIC BALANCER	1		
22	10	53833	BOLT, PULLEY (1")	3		
23	13	35048	LOCKWASHER, PULLEY BOLT	3		
23	13	35048	LOCKWASHER, PULLEY BOLT	3		
24	12	34714	WASHER, PULLEY BOLT	3		
25		14249A	COVER, CRANKCASE FRONT	1		
26	26	97335	OIL SEAL, COVER	1		2
27	27	14250	GASKET, COVER	1		2
28	10	35366	SCREW, COVER	10		
29		11972	ADAPTOR, OIL FILTER	1		
30		41815	OIL FILTER	1		
32		75435A	TIMING POINTER	1		
33		14229	RETAINER, OIL SEAL (REAR)	1		