



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	50	97499A 2	STARTER MOTOR ASSEMBLY	1		
1		79206	HOUSING, DRIVE END	1		
2	23	33278	BUSHING, DRIVE END HOUS	1		
3		33292	COLLAR, THRUST	1		
4	53	33290	RING, RETAINING - PINION ST	1		
5		33291	COLLAR, PINION STOP	1		
6		68609	DRIVE ASSEMBLY, CLUTCH	1		
7		79396	PLATE, BEARING	1		
8	23	71694	BUSHING, BEARING PLATE	1		
9	12	68614	WASHER, BEARING PLATE	1		
10	10	79209	SCREW, BEARING PLATE	2		
11		N.S.S.	ARMATURE (DELCO REMY #1E	1		
12		N.S.S.	SHOE, POLE - FIELD COIL (DEL	4		
13		N.S.S.	SCREW, POLE SHOE TO FIELD	4		
14		N.S.S.	INSULATION, FIELD COIL (DEL	1		
15	25	79208	GROMMET, FIELD COIL - FIELD	1		
16		79212	FIELD COIL ASSEMBLY	1		
17	12	68613	WASHER, LEATHER - COMMU	1		
18		79211	FRAME, COMMUTATOR END -I	1		
19		N.S.S.	BOLT, THRU (DELCO REMY #1	2		
20		33284	HOLDER, INSULATED - FIELD F	2		
21		33283	HOLDER, FIELD FRAME BRUSH	2		
22		33270	BRUSH, FIELD FRAME	4		
23		N.S.S.	SCREW, BRUSH LEAD (DELCO	2		
24		N.S.S.	SCREW, BRUSH LEAD (DELCO	2		
25	24	33285	SPRING, FIELD FRAME BRUSH	4		
26		N.S.S.	PIN, DOWEL - FIELD FRAME (D	1		
27		33297	LEVER, SHIFT	1		
28		N.S.S.	STUD, SHIFT LEVER (DELCO R	1		
29	12	68615	WASHER, SHIFT LEVER STUD	1		
30	11	26484	NUT, SHIFT LEVER STUD	1		
31		N.S.S.	PLUNGER, SHIFT LEVER (DEL	1		
32	17	79207	PIN, PLUNGER TO SHIFT LEVE	1		
33		N.S.S.	SPRING, PLUNGER RETURN (E	1		
34		N.S.S.	SCREW, SOLENOID SWITCH (E	2		
35		13037	SOLENOID SWITCH (4-1/4" LO	1		
35	89	18080	SOLENOID SWITCH (3-5/8" LO	1		