



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	735	8938	PISTON AND PISTON PIN ASSEM	AR		
1	735	8939	PISTON AND PISTON PIN ASSEM	AR		
1	735	8967	PISTON AND PISTON PIN ASSEM	AR		
2	39	75609	RING, PISTON (STANDARD)	6		
2	39	75981	RING, PISTON (.030 O.S.)	AR		
3	23	85694	BEARING UNIT, CRANKSHAFT (S	3		
3	23	85695	BEARING UNIT, CRANKSHAFT M	AR		
3	23	85696	BEARING UNIT, CRANKSHAFT M	AR		
3	23	85697	BEARING UNIT, CRANKSHAFT M	AR		
4	23	85698	BEARING UNITL, CRANKSHAFT	1		
4	23	85699	BEARING UNIT, CRANKSHAFT M	AR		
4	23	85700	BEARING UNIT, CRANKSHAFT M	AR		
4		N.S.S.	BEARING UNIT, REAR (.020 U.S.)	AR		
5		N.S.S.	PIN, DOWEL - REAR BEARING C	2		
6	26	58203	OIL SEAL, REAR BEARING CAP	2		
7	222	6355	FLYWHEEL	1		
8	10	49845	SCREW, FLYWHEEL TO CRANKS	6		
9	13	39131	LOCKWASHER, FLYWHEEL SCR	6		
10		76850A	2 COUPLING ASSEMBLY	1		
11	16	98532A	1 STUD, COUPLER TO FLYWHEEL	6		
12	12	35935	WASHER, COUPLER TO FLYWHE	6		
13	11	98533	NUT, COUPLER STUDS TO FLYW	6		
14	614	8937	CONNECTING ROD ASSEMBLY	6		
15	10	85802	BOLT, CONNECTING ROD CAP	12		
16	11	37493	NUT, CONNECTING ROD CAP E	12		
17	23	42765	BEARING UNIT (PAIR), CONNECT	6		
17		474096	BEARING UNIT (PAIR), CONNECT	AR		
17		474097	BEARING UNIT (PAIR), CONNECT	AR		
17	23	42766	BEARING UNIT (PAIR), CONNECT	AR		
17	23	42767	BEARING UNIT (PAIR), CONNECT	AR		
18	429	8936	CRANKSHAFT	1		
19	28	34466	KEY, CRANKSHAFT PULLEY AND	2		