



Parts List					
Ref	Class	Part	Description	Qty	Footnote
	50	99417A 2	STARTER MOTOR ASSEMBLY	1	
1		71696	HOUSING,DRIVE END	1	
2	23	33369	BRUSHING,DIRVE END HOUSII	1	
3		33292	COLLAR, THURST	1	
4	53	33290	RING, RETAINING-PINION STOP	1	
5		33291	COLLAR, PINION STOP	1	
6		79205	DRIVE ASSEMBLY, CLUTCH	1	
7		N.S.S.	PLATE, BEARING (DELCO REMY	1	
8	23	71694	BUSHING, BEARING PLATE	1	
9	12	68614	WASHER, BEARING PLATE	1	
10	10	79209	SCREW, BEARING PLATE	2	
11		75665	ARMATURE	1	
12		N.S.S.	SHOE, POLE-FIELD COIL (DELCO	4	
13		N.S.S.	SCREW, POLE SHOE TO FIED CC	4	
14	25	79208	GORMMET, FIELD COIL-FIELD FF	1	
15		75664	FIELD COIL ASSEMBLY	1	
16	12	33258	WASHER, LEATHER-COMMUTAT	1	
17		79211	FRAME, COMMUTATOR END-LOA	1	
18		N.S.S.	BOLT, THRU (DELCO REMY #192	1	
18		N.S.S.	BOLT, THRU (DELCO REMY #193	1	
19		33284	HOLDR, INSULATED-FIELD FRAM	2	
20		33283	HOLDER, FIELD FRAME BRUSH	2	
21		33270	BRUSH, FIELD FRAME		
22		N.S.S.	SCREW, BRUSH LEAD (DELCO R	2	
22		N.S.S.	SCREW, BRUSH LEAD (DELCO R	2	
23		33294	SUPPORT PACKAGE, GROUND A	2	
24	24	33285	SPRING, FIELD FRAME BRUSH	4	
25		N.S.S.	PIN, DOWEL-FIELD FRAME (DEL	1	
26		33297	LEVER, SHIFT	1	
27		N.S.S.	STUD, SHIFT LEVER (DELCO REI	1	
28	12	68615	WASHER, SHIFT LEVER STUD	1	
29	11	26484	NUT, SHIFT LEVER STUD	1	
30		33317	PLUNGER, SHIFT LEVER	1	
31	17	79207	PIN, PLUNGER TO SHIFT LEVER	1	
32		N.S.S.	SPRING, PLUNGER RETURN (DE	1	
33		N.S.S.	SCREW, SOLENOID SWITCH (DE	2	
34		33261	SOLENOID SWITCH ASSEMBLY	1	