



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		42752	INTAKE MANIFOLD	1		
2	10	26487	BOLT, INTAKE MANIFOLD	8		
2		N.S.S.	BOLT, INTAKE MANIFOLD (GM #)	4		
3	12	49112	WASHER, INTAKE MANIFOLD BC	8		
4		42453	BRASCKER, LIFTING (FRONT)	1		
4		42745	BRACKET, LIFTING (REAR)	1		
5	10	34354	SCREW, LIFTING BRACKET (1-1/	1		
6		N.S.S.	STUD, GUARD TO INTAKE MANIF	4		
7		42753	GUARD, INTAKE MANIFOLD	1		
8	27	42763	GASKET SET, INTAKE MANIFOLD	1		4
9		60658	WATER PUMP ASSEMBLY	1		
10	27	34897	GASKET, WATER PUMP MOUN	2		2
11	22	48336	PLUG, WATER PUMP	1		
12	10	32132	SCREW, WATER PUMP TO CYLIN	1		
12	10	47688	SCREW, WATER PUMP TO CYLIN	1		
12	10	52200	SCREW, WATER PUMP TO CYLIN	1		
12		N.S.S.	STUD, WATER PUMP TO CYLIN	1		
13		90840A	PULLEY, WATER PUMP (3 GROO	1		
14	10	47277	SCREW, PULLEY TO WATER PU	4		
15	13	39107	LOCKWASHER, WATER PUMP P	4		
16		42746	BALANCER, HARMONIC - CRANK	1		
17		33863	PULLEY, HARMONIC BALANCER	1		
18		90841A	PULLEY, (1 GROOVE) - W/POWE	1		
19	10	72626	BOLT, PULLEY AND HARMONIC	1		
20	13	39131	LOCKWASHER, PULLEY AND HA	1		
21	12	35332	WASHER, PULLEY AND HARMON	1		
22	10	34352	BOLT, PULLEY (7/8") - W/O POW	3		
22	10	35786	BOLT, PULLEY (1") - W/POWER	3		
23	13	35048	LOCKWASHER, PULLEY BOLT	3		
24	57	49213A	BELT, ALTERNATOR DRIVE (44"	1		
25		42749	COVER ASSEMBLY, CRANKCASE	1		
26	26	42750	OIL SEAL, CRANKCASE FRONT	1		
27	27	34895	GASKET, CRANKCASE FRONT EN	1		2
28	10	35366	SCREW, CRANKCASE FRONT EN	10		
29		42795	ADAPTOR, OIL FILTER	1		
30		41815	OIL FILTER	1		
31		42697	REINFORCEMENT, CRANKSHAF	1		