




Parts List

Ref	Class	Part	Description	Qty	
1		98348A 4	INTAKE MANIFOLD ASSEMBLY	1	
2	22	32802	PLUG, INTAKE MANIFOLD - TOP	1	
3	10	28642	DRIVE SCREW, WATER TUBE FLANGE	4	
4	27	70905	GASKET, INTAKE MANIFOLD	1	
5	10	68101	SCREW, INTAKE MANIFOLD TO CYLINDER HEAD (1-3/8")	7	
6	12	25909	WASHER, INTAKE MANIFOLD SCREW	5	
6	12	55149	WASHER, INTAKE MANIFOLD SCREW	2	
7	22	73817	FITTING, INTAKE MANIFOLD	1	
8	32	89713	HOSE, INTAKE MANIFOLD TO RESERVIOR	1	
9	54	54428	CLAMP, HOSE ATTACHING	2	
10		98350A 1	COVER, OIL COOLER	1	
11	25	42357	"O" RING, OIL COOLER COVER	1	
12	10	76596	SCREW, OIL COOLER COVER	10	
13	13	26992	LOCKWASHER, COVER SCREW	10	
14	32	76326	HOSE, INTAKE MANIFOLD TO WATER PUMP	1	
15	54	32780	CLAMP, HOSE TO WATER PUMP	1	
16	54	32781	CLAMP, HOSE TO INTAKE MANIFOLD	1	
17	32	89655	HOSE, INTAKE MANIFOLD	1	
18	54	32781	CLAMP, HOSE TO INTAKE MANIFOLD	2	