



| Parts List |       |          |                              |     |         |          |
|------------|-------|----------|------------------------------|-----|---------|----------|
| Ref        | Class | Part     | Description                  | Qty | Comment | Footnote |
| 1          | 45    | 94819A 3 | DRIVE SHAFT ASSEMBLY         | 1   |         |          |
| 2          |       | 52504    | FLANGE, DRIVE SHAFT          | 2   |         |          |
| 3          |       | 61221    | COVER AND BEARING KIT        | 2   |         |          |
| 4          | 22    | 74036    | GREASE FITTING               | 2   |         |          |
| 5          | 10    | 52498    | SCREW, DRIVE SHAFT FLANGE    | 8   |         |          |
| 6          | 11    | 34933    | NUT, FLANGE SCREW            | 8   |         |          |
| 7          |       | 93913A 3 | BEARING SUPPORT ASSEMBLY     | 1   |         |          |
| 8          | 26    | 93924    | OIL SEAL                     | 1   |         |          |
| 9          | 30    | 93944A 1 | BALL BEARING                 | 1   |         |          |
| 10         | 53    | 93914    | SNAP RING, BALL BEARING      | 1   |         |          |
| 11         | 22    | 74036    | GREASE FITTING               | 1   |         |          |
| 12         |       | 93908A 1 | SHAFT ASSEMBLY, INPUT        | 1   |         |          |
| 13         | 19    | 93921    | EXPANSION PLUG               | 1   |         |          |
| 14         | 53    | 93915    | SNAP RING, INPUT SHAFT       | 1   |         |          |
| 15         | 22    | 74036    | GREASE FITTING               | 1   |         |          |
| 16         |       | 93918A 1 | SHIELD ASSEMBLY, LOWER       | 2   |         |          |
| 17         | 10    | 76926    | SCREW, LOWER SHIELD TO SUF   | 6   |         |          |
| 18         |       | 93919A 1 | SHIELD ASSEMBLY, UPPER       | 2   |         |          |
| 19         | 10    | 96995    | SCREW, UPPER AND LOWER SH    | 8   |         |          |
| 20         | 11    | 99405    | NUT, SHIELD SCREW            | 8   |         |          |
| 21         |       | 93906A 1 | SHAFT ASSEMBLY, OUTPUT       | 1   |         |          |
| 22         | 25    | 25439    | "O" RING                     | 2   |         |          |
| 23         | 53    | 94104    | SNAPRING, BALL BEARING, INTE | 1   |         |          |
| 24         | 30    | 62780A 1 | BALL BEARING                 | 1   |         |          |
| 25         |       | 49736A 3 | COUPLING ASSEMBLY            | 1   |         |          |
| 26         | 23    | 95966    | BUSHING, COUPLING            | 1   |         |          |
| 27         | 12    | 34567    | WASHER, HOUSING SCREW        | 6   |         |          |
| 28         | 11    | 98533    | NUT, HOUSING SCREW           | 6   |         |          |
| 29         | 53    | 94103    | SNAP RING, EXTERNAL          | 1   |         |          |
| 30         | 10    | 57053    | BOLT, BEARING SUPPORT (4-1/2 | 2   |         |          |
| 31         | 12    | 32552    | WASHER, BEARING SUPPORT B    | 2   |         |          |
| 32         | 12    | 42307    | WASHER, BEARING SUPPORT B    | 4   |         |          |
| 33         | 11    | 28040    | NUT, BEARING SUPPORT BOLT    | 2   |         |          |