



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		66057A 3	SHIFT BRACKET ASSEMBLY	1		
2	16	79661	STUD, SHIFT CABLE TO BRACK	1		
3	16	73563	STUD, SWITCH ACTUATING AF	1		
4	12	39143	WASHER, SHIFT CABLE TO LEVE	2		
5	11	20361	NUT, SHIFT BRACKET STUD	2		
6	10	52498	SCREW, SHIFT BRACKET TO FLY	2		
7	12	22248	WASHER, SHIFT BRACKET ATTA	2		
8		76812A 4	REVERSE LOCK VALVE ASSEMB	1		
9	22	45794	ELBOW, HUDRAULIC TRIM HO	1		
10	22	48167	CONNECTOR, ELBOW	1		
11		45709	FOLLOWER, CAM	1		
12	13	25906	WASHER, WAVE - REVERSE LI	1		
13	25	45710	"O" RING, REVERSE LOCK VAL	1		
14		45526	CAM, REVERSE LOCK VALVE	1		
15	10	46736	SCREW, CAM TO CAM LEVER	1		
16	13	26996	LOCKWASHER, CAM SCREW	1		
17	12	45713	WASHER, RETAINING - BALL T	1		
18	30	45712	BALL, VALVE COVER	30		
19		45528A 2	COVER ASSEMBLY, REVERSE	1		
20	25	45711	"O" RING, VALVE COVER	1		
21	12	59570	WASHER, VALVE COVER	1		
22	10	45716	SCREW, COVER TO REVERSE	4		
23	11	20110	NUT, COVER SCREW	4		
24	22	52644	PLUG, PIPE - REVERSE LOCK V	1		
25		46732A 1	LEVER ASSEMBLY, CAM	1		
26	16	45715	STUD, SHIFT CONTROL LEVE	2		
29	10	25299	SCREW, REVERSE LOCK VALVE	2		
30	13	21804	LOCKWASHER, REVERSE LOCK	2		
31	12	21273	WASHER, CAM LEVER STUD	2		
32	11	20110	NUT, SHIFT CONRTOLEVER TO	2		
33		66397A 1	LEVER ASSEMBLY, SHIFT CONTI	1		
34	16	63081	STUD, SHIFT CABLE TO LEVEF	1		
35	23	31866	SPACER, SHIFT LEVER STUD	1		
36	12	39143	WASHER, SHIFT LEVER STUD	2		
37	11	20361	NUT, SHIFT CABLE TO LEVER :	1		
38	16	63335	STUD, SHIFT CABLE TO SHIFT	1		
40	11	63341	TEE NUT, SHIFT CABLE TO SH	1		
41		45517A 2	ARM ASSEMBLY, SWITCH ACTU	1		
42	10	33231	SCREW, TENSION SPRING TO	1		
43	12	26825	WASHER, TENSION SPRING SI	1		
44	24	45599	SPRING, TENSION, SWITCH A	1		