





**BREAKDOWN
 OF WATER
 PUMP**



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	46	47506A 1	WATER PUMP ASSEMBLY, COM	1		
2		52822	PULLEY, WATER PUMP	1		
3		47530	HUB, WATER PUMP PULLEY	1		
4	10	20705	SCREW, WATER PUMP PULLE	4		
5	13	39107	LOCKWASHER, WATER PUMP	4		
6		47403	SHAFT AND BEARING	1		
7	53	47657	RING, RETAINING - SGAFT AN	1		
8	12	47683	WASHER, SHAFT AND BEARIN	1		
9	26	47401	SEAL, MECHANICAL-SHAFT AN	1		
10	26	47531	SEAL, FLOATING-SHAFT AND E	1		
11	46	47506A 2	BODY ASSEMBLY, WATER PUM	1		
12		47405	WEAR PLATE	2		
13		47529	INSERT, WATER PUMP BOD	1		
14	47	47519	IMPELLER	1		
15	17	47526	PIN, IMPELLER DRIVE	1		
16		47497A 1	COVER ASSEMBLY, WATER PL	1		
17	23	47511	SLEEVE, WATER PUMP COVE	2		
18	27	47410	GASKET, WATER PUMP COVE	1		
19	10	28635	SCREW, WATER PUMP COVE	6		
20	23	52133	HOSE, WATER PUMP TO THERM	1		
21	54	32780	CLAMP, HOSE TO WATER PUM	2		
22	54	47715	CLIP, HOSE TO EXHAUST MANIF	1		
23	10	27165	SCREW, HOSE CLIP TO EXHAUS	1		
24	13	35048	LOCKWASHER, HOSE CLIP SCRE	1		
25	11	28517	NUT, HOSE CLIP SCREW	1		
26		49587	BRACE, WATER PUMP ADJUSTI	1		
27	10	31381	SCREW, ADJUSTING BRACE TO	1		
28	13	32993	LOCKWASHER, ADJUSTING BRA	1		
29	10	26632	SCREW, ADJUSTING BRACE TO	1		
30	12	20553	WASHER, ADJUSTING BRACE SI	1		
31	13	35048	LOCKWASHER, ADJUSTING BRA	1		
32	11	28517	NUT, ADJUSTING BRACE SCREW	1		
33		49581	BRACKET, WATER PUMP	1		
34	10	34354	SCREW, WATER PUMP BRACKE	1		
35	13	35048	LOCKWASHER, WATER PUMP B	1		
36	10	52409	SCREW, WATER PUMP BRACKE	1		
37	23	33186	BUSHING, WATER PUMP BRACK	1		
38	11	23161	NUT, WATER PUMP BRACKET S	1		
39	57	45367	BELT, WATER PUMP	1		