



DISTRIBUTOR AND IGNITION COMPONENTS

| Parts List | | | | | | |
|------------|-------|-----------|--------------------------------|-----|---------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | | 90747A15 | DISTRIBUTOR ASSEMBLY | 1 | | |
| 2 | | 13753A 2 | CAP, DISTRIBUTOR | 1 | | |
| 3 | 10 | 90926 | SCREW, DISTRIBUTOR CAP | 4 | | |
| 4 | 27 | 98242 1 | GASKET, DISTRIBUTOR CAP | 1 | | |
| 5 | | 13524A 6 | ROTOR/SENSOR WHEEL | 1 | | |
| 11 | 87 | 91019A 3 | SENSOR ASSEMBLY | 1 | | |
| 12 | 10 | 66686 | SCREW, SENSOR (1") | 1 | | |
| 12 | 10 | 72202 | SCREW, SENSOR (1-1/4") | 1 | | |
| 13 | 43 | 813776 1 | GEAR, DRIVE | 1 | | |
| 14 | 17 | 47617 | PIN, DRIVE GEAR | 1 | | |
| 15 | 27 | 34486 3 | GASKET, DISTRIBUTOR | 1 | | 2 |
| 16 | | 52185 | CLAMP, DISTRIBUTOR TO INTAK | 1 | | |
| 17 | 10 | 11976 | SCREW, DISTRIBUTOR CLAMP (| 1 | | |
| 18 | 13 | 26996 | LOCKWASHER, DISTRIBUTOR T | 2 | | |
| 19 | 11 | 68219 | NUT, DISTRIBUTOR TERMINAL (| 2 | | |
| 20 | 84 | 813720A11 | SPARK PLUG WIRE KIT | 1 | | |
| 21 | 85 | 63709A 1 | BOOT ASSEMBLY, SPARK PLUG | 8 | | |
| 22 | 33 | 59571 | SPARK PLUG | 8 | | |
| 23 | | 54676 | RETAINER, HIGH TENSION LEAD | 2 | | |
| 24 | | 32783 | RETAINER, HIGH TENSION LEAD | 4 | | |
| 25 | | 32784 | RETAINER, HIGH TENSION LEAD | 2 | | |
| 26 | 392 | 7803A 4 | COIL, IGNITION | 1 | | |
| 27 | | 65970 | BRACKET, IGNITION COIL | 1 | | |
| 28 | 10 | 41408 | SCREW, BRACKET (1-1/2") | 1 | | |
| 29 | 12 | 30164 | WASHER, IGNITION COIL TERMINAL | 2 | | |
| 30 | 13 | 26996 | LOCKWASHER, IGNITION COIL T | 2 | | |
| 31 | 11 | 68219 | NUT, IGNITION COIL TERMINAL | 2 | | |
| 32 | 10 | 98260 | SCREW, IGNITION COIL | 1 | | |
| 33 | 13 | 35048 | LOCKWASHER, IGNITION COIL S | 1 | | |
| 34 | 16 | 90096A 1 | STUD ASSEMBLY - NEW DESIGN | 2 | | |
| 35 | 54 | 72821 | RETAINER, WIRE - NEW DESIGN | 2 | | |