



| Parts List | | | | | | |
|------------|-------|----------|------------------------------|-----|---------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | | 41141A 2 | FUEL PUMP | 1 | | |
| 2 | 35 | 11004 | FUEL FILTER | 1 | | |
| 3 | 27 | 34213 | GASKET, FUEL PUMP TO CYLIND | 1 | | 2 |
| 4 | 10 | 31984 | SCREW, FUEL PUMP | 2 | | |
| 5 | 13 | 39107 | LOCKWASHER, FUEL PUMP SCR | 2 | | |
| 6 | | 42454 | PLATE, FUEL PUMP MOUNTING | 1 | | |
| 7 | 27 | 42457 | GASKET, FUEL PUMP MOUNTING | 1 | | 2 |
| 8 | 10 | 35366 | SCREW, FUEL PUMP MOUNTING | 2 | | |
| 9 | | 17347 | ROD, PUSH - FUEL PUMP | 1 | | |
| 10 | 32 | 73815 63 | HOSE, PLASTIC - FUEL PUMP TO | 1 | | |
| 11 | 22 | 43276 | ELBOW, FUEL PUMP | 1 | | |
| 12 | 32 | 11851 2 | FUEL LINE, FUEL PUMP TO CAR | 1 | | |
| 12 | 32 | 99755A 2 | FUEL LINE, FUEL PUMP TO CAR | 1 | | |