



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		11974	INTAKE MANIFOLD (175 - 4.3L)	1	
1		42752	INTAKE MANIFOLD (205 - 4.3L/LX)	1	
2	10	11976	BOLT, INTAKE MANIFOLD	8	
2	10	11975	BOLT, INTAKE MANIFOLD	4	
3	22	75983	PLUG, VACUUM HOLE	1	
4		42453	BRACKET, LIFTING (FRONT)	1	
4		42745	BRACKET, LIFTING (REAR)	1	
5	10	34354	SCREW, LIFTING BRACKET (1-1/2")	1	
6		N.S.S.	STUD, GUARD TO INTAKE MANIFOLD	4	
7		42753	GUARD, INTAKE MANIFOLD	1	
8	27	11977	GASKET SET, INTAKE MANIFOLD	1	2
9		17437	WATER PUMP ASSEMBLY	1	
10	27	34897	GASKET, WATER PUMP MOUNT	2	2
11	22	48336	PLUG, WATER PUMP	1	
12	10	32132	SCREW, WATER PUMP TO CYLINDER	1	
12	10	47688	SCREW, WATER PUMP TO CYLINDER	1	
12	10	52200	SCREW, WATER PUMP TO CYLINDER	1	
12		N.S.S.	STUD, WATER PUMP TO CYLINDER	1	
13		15120T	PULLEY, WATER PUMP (5-1/2" C)	1	
13		19692T	PULLEY, WATER PUMP (7" DIA.)	1	
14	10	47277	SCREW, PULLEY TO WATER PUMP	4	
15	13	39107	LOCKWASHER, WATER PUMP PULLEY	4	
16		11990	BALANCER, CRANKSHAFT	1	
17		90081T	PULLEY, HARMONIC BALANCER	1	
18	57	49213A	BELT (44") (USE WITH 5-1/2" DIA. PULLEY)	1	
18	57	48120A	BELT (46") (USE WITH 7" DIA. PULLEY)	1	
19	10	32515	BOLT, PULLEY AND HARMONIC BALANCER	1	
20	13	39131	LOCKWASHER, PULLEY AND HARMONIC BALANCER	1	
21	12	35332	WASHER, PULLEY AND HARMONIC BALANCER	1	
22	10	53833	BOLT, PULLEY (1")	3	
23	13	35048	LOCKWASHER, PULLEY BOLT	3	
23	13	35048	LOCKWASHER, PULLEY BOLT	3	
24	12	34714	WASHER, PULLEY BOLT	3	
25		14249A	COVER, CRANKCASE FRONT	1	
26	26	97335	OIL SEAL, COVER	1	2
27	27	14250	GASKET, COVER	1	2
28	10	35366	SCREW, COVER	10	
29		11972	ADAPTOR, OIL FILTER	1	
30		41815	OIL FILTER	1	
32		75435A	TIMING POINTER	1	
33		14229	RETAINER, OIL SEAL (REAR)	1	