



**CAST  
MOUNTING  
BRACKET**

| Parts List |       |          |                             |     |         |          |
|------------|-------|----------|-----------------------------|-----|---------|----------|
| Ref        | Class | Part     | Description                 | Qty | Comment | Footnote |
| 1          |       | 90496A   | PUMP ASSEMBLY, POWER STEE   | 1   |         |          |
| 1A         | 16    | 41877    | STUD, POWER STEERING PUM    | 1   |         |          |
| 2          | 36    | 95805    | CAP, POWER STEERING PUMF    | 1   |         |          |
| 3          |       | 73873A   | PULLEY, POWER STEERING PI   | 1   |         |          |
| 4          | 12    | 34567    | WASHER, PUMP STUD (BRACE    | 1   |         |          |
| 5          | 11    | 90517    | NUT, MOUNTING STUD          | 2   |         |          |
| 6          |       | 98644A   | BRACE, PUMP MOUNTING        | 1   |         |          |
| 7          | 10    | 40001188 | SCREW, PUMP MOUNTING BRA    | 1   |         |          |
| 8          | 13    | 40024    | LOCKWASHER, BRACE SCREW     | 1   |         |          |
| 9          | 57    | 37619T   | V-BELT, POWER STEERING PUM  | 1   |         |          |
| 10         | 32    | 90494    | HOSE, PRESSURE (FITTINGS ON | 1   |         |          |
| 11         | 25    | 89879    | "O" RING, PRESSURE HOSE EI  | 1   |         |          |
| 12         | 32    | 98843    | HOSE, RETURN (FITTINGS ON O | 1   |         |          |
| 13         | 32    | 52519    | HOSE, PUMP TO OIL COOLER    | 1   |         |          |
| 14         | 54    | 35830    | CLAMP, HOSE ATTACHING       | 3   |         |          |