



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	46	58001A 4	WATER PUMP ASSEMBLY, COM	1	SERIAL 00000000-03040410	
2	26	23300	OIL SEAL, WATER PUMP SHAF	2	SERIAL 02907035-03040410	
3	30	20861	BALL BEARING, WATER PUMP	2	SERIAL 02907035-03040410	
4		57967	SHAFT, WATER PUMP	1	SERIAL 02907035-03040410	
5	53	23720	RING, SNAP - BALL BEARING R	1	SERIAL 02907035-03040410	
6	26	58111	OIL SEAL, WATER PUMP SHAFT	1	SERIAL 02907035-03040410	
7	26	47531	SEAL, FLOATING - WATER PUM	1	SERIAL 00000000-02907034	
8	26	47401	SEAL, MECHANICAL - WATER F	1	SERIAL 00000000-02907034	
9	12	47683	WASHER, WATER PUMP SHAF	1	SERIAL 00000000-02907034	
10	53	47657	RING, RETAINING - WATER PU	1	SERIAL 00000000-02907034	
11		47403	SHAFT, WATER PUMP	1	SERIAL 00000000-02907034	
12		47530	HUB, WATER PUMP PULLEY S	1	SERIAL 00000000-03040410	
13		47405	WEAR PLATE	2	SERIAL 00000000-03040410	
14		47529	INSERT, WATER PUMP	1	SERIAL 00000000-03040410	
15	47	47519	IMPELLER	1	SERIAL 00000000-03040410	
16	17	47526	PIN, IMPELLER DRIVE	1	SERIAL 00000000-03040410	
17		47497A 1	COVER ASSEMBLY, WATER PL	1	SERIAL 00000000-03040410	
18	23	47511	SLEEVE, WATER PUMP COVE	2	SERIAL 00000000-03040410	
19	27	47410	GASKET, WATER PUMP COVE	1	SERIAL 00000000-03040410	
20	10	28635	SCREW, WATER PUMP COVE	6	SERIAL 00000000-03040410	
1	46	59112A 2	WATER PUMP ASSEMBLY, COM	1	SERIAL 03040411-09999999	
17		59155	COVER, WATER PUMP	1	SERIAL 03040411-09999999	
18	10	28635	SCREW, COVER TO WATER PL	6	SERIAL 03040411-09999999	
19	25	59712	"O" RING, WATER PUMP COVE	1	SERIAL 03040411-09999999	
20	19	59504	PLUG, IMPELLER	1	SERIAL 03040411-09999999	
21	47	59362A 1	IMPELLER ASSEMBLY	1	SERIAL 03040411-09999999	
22	28	56662	KEY, IMPELLER DRIVE	2	SERIAL 03040411-09999999	
23		59363A 1	CAM SEGMENT ASSEMBLY	1	SERIAL 03040411-09999999	
24	10	60777	SCREW, CAM SEGMENT ATTAI	1	SERIAL 03040411-09999999	
25		59503	WEAR PLATE, IMPELLER	1	SERIAL 03040411-09999999	
26	23	47511	SLEEVE, WATER PUMP	2	SERIAL 03040411-09999999	
27	26	23300	OIL SEAL, WATER PUMP SHAF	2	SERIAL 03040411-09999999	
28	30	20861	BALL BEARING, WATER PUMP	2	SERIAL 03040411-09999999	
29		59501	SHAFT, WATER PUMP	1	SERIAL 03040411-09999999	
30	53	23720	RING, SNAP - BALL BEARING R	1	SERIAL 03040411-09999999	
31	26	59564	OIL SEAL, WATER PUMP SHAF	1	SERIAL 03040411-09999999	
32		47530	HUB, WATER PUMP PULLEY	1	SERIAL 03040411-09999999	
33		52822	PULLEY, WATER PUMP	1	SERIAL 00000000-03040410	
33		59762	PULLEY, WATER PUMP	1	SERIAL 03040411-09999999	
34	10	47277	SCREW, WATER PUMP PULLEY	4		
35	12	28107	LOCK WASHER, WATER PUMP	4		