



| Parts List | | | | | | |
|------------|-------|----------|-----------------------------|-----|----------------------------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | | 45060A 7 | HYDRAULIC PUMP ASSEMBLY | 1 | SEE PAGE 19 FOR PARTS BREA | |
| 2 | 25 | 21720 | "O" RING, HYDRAULIC PUMP T | 4 | | |
| 3 | 10 | 46318 | SCREW, VENT - HYDRAULIC PI | 1 | | |
| 4 | 13 | 46317 | LOCKWASHER, SEALING - VEN | 1 | | |
| 5 | 10 | 28634 | SCREW, FILLER - HYDRAULIC I | 1 | | |
| 6 | 12 | 20260 | WASHER, SEALING - HYDRAUL | 1 | | |
| 7 | | 48077A 4 | CONTROL VALVE ASSEMBLY | 1 | | |
| 7 | 25 | 21720 | "O" RING, HYDRAULIC PUMP T | 4 | SEE REFERENCE #2 | |
| 8 | 22 | 52666 | ELBOW, CONTROL VALVE | 1 | | |
| 9 | 10 | 20653 | SCREW, CONTROL VALVE TO H | 4 | | |
| 10 | 13 | 26392 | LOCKWASHER, CONTROL VALVE | 4 | | |
| 11 | 38 | 55823 | DECAL, INSTRUCTIONS - HYDRA | 1 | | |
| 12 | | 57823 | BRACKET, MOUNTING - HYDRAL | 1 | HYDRAULIC SHIFT | |
| 13 | 10 | 26066 | SCREW, HYDRAULIC PUMP TO H | 6 | HYDRAULIC SHIFT | |
| 14 | 12 | 20546 | WASHER, HYDRAULIC PUMP SC | 6 | HYDRAULIC SHIFT | |
| 15 | 11 | 35814 | NUT, HYDRAULIC PUMP SCREW | 6 | HYDRAULIC SHIFT | |
| 15 | | 55642A 3 | CONTROL PANEL ASSEMBLY, CC | 1 | HYDRAULIC SHIFT | |
| 16 | | 55642A 1 | PANEL ASSEMBLY, CONTROL | 1 | HYDRAULIC SHIFT | |
| 17 | 16 | 55422 | STUD, CONTROL PANEL TO BC | 4 | HYDRAULIC SHIFT | |
| 18 | 12 | 24676 | WASHER, CONTROL PANEL ST | 4 | HYDRAULIC SHIFT | |
| 19 | 11 | 27164 | NUT, CONTROL PANEL STUD | 4 | HYDRAULIC SHIFT | |
| 20 | | 55738A 1 | SWITCH, PUSH BUTTON - CON | 3 | HYDRAULIC SHIFT | |
| 21 | | 48078 | JUMPER WIRE, PUSH BUTTON | 1 | HYDRAULIC SHIFT | |
| 21 | | 53107 | JUMP WIRE, PUSH BUTTON SW | 1 | HYDRAULIC SHIFT | |
| 22 | | 55641 | RETAINER, PUSH BUTTON SW | 1 | HYDRAULIC SHIFT | |
| 23 | 10 | 30663 | SCREW, SWITCH RETAINER T | 4 | HYDRAULIC SHIFT | |
| 24 | | 45341 20 | HARNES, CONTROL PANEL | 1 | HYDRAULIC SHIFT | |
| 25 | | 33865 | BINDER, NYLON - CONTROL PA | 1 | HYDRAULIC SHIFT | |
| 26 | 54 | 46770 | CLAMP, HARNES ATTACHING | 1 | HYDRAULIC SHIFT | |
| 27 | 10 | 29227 | SCREW, HARNES ATTACHING | 1 | HYDRAULIC SHIFT | |
| 28 | 11 | 34388 | NUT, HARNES ATTACHING CI | 1 | HYDRAULIC SHIFT | |
| 29 | | 57756 | WIRING HARNES, HYDRAULIC | 1 | ELECTRIC SHIFT | |
| 30 | | 45377 | BRACKET, MOUNTING - HYDRAL | 2 | ELECTRIC SHIFT | |
| 31 | 10 | 28009 | SCREW, PUMP MOUNTING BRA | 2 | ELECTRIC SHIFT | |
| 32 | 11 | 35304 | NUT, PUMP MOUNTING BRACK | 2 | ELECTRIC SHIFT | |
| 33 | 10 | 24234 | SCREW, HYDRAULIC PUMP TO H | 4 | ELECTRIC SHIFT | |
| 34 | 13 | 39107 | LOCKWASHER, HYDRAULIC PUM | 4 | ELECTRIC SHIFT | |
| 35 | 11 | 21908 | NUT, HYDRAULIC PUMP SCREW | 4 | ELECTRIC SHIFT | |
| 36 | | 58397A 2 | BRACKET, MOUNTING - HYDRAL | 1 | ELECTRIC SHIFT | |
| 37 | | 58491 | BUMPER, RUBBER - PUMP MO | 2 | ELECTRIC SHIFT | |
| 38 | 10 | 58784 | SCREW, PUMP MOUNTING BRA | 2 | ELECTRIC SHIFT | |