



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		47551	PANEL, ELECTRIC	1		
2	22	32802	PLUG, PIPE - ELECTRIC PANEL (1		
2	22	36737	PLUG, PIPE - ELECTRIC PANEL (1		
3		47763	BRACKET, RETAINER - HIGH TEN	2		
4	25	38930	GROMMET, HIGH TENSION LEAD	2		
5	10	20776	SCREW, RETAINER BRACKET TI	2		
6	13	26992	LOCKWASHER, RETAINER BRAC	2		
7		25661	STARTER SOLENOID	1,1		
8	13	26993	LOCKWASHER, STARTER SOLEI	2,2		
9	11	20083	NUT, STARTER SOLENOID TERM	2,2		
9		46265	BOOT, STARTER MOTOR TERMI	,1		
10	13	26996	LOCKWASHER, STARTER SOLEI	2,2		
11	11	20645	NUT, STARTER SOLENOID TERM	2,2		
12	10	26774	SCREW, STARTER SOLENOID TI	2		
13	13	26992	LOCKWASHER, STARTER SOLEI	2		
12	10	21623	SCREW, STARTER SOLENOID A	2		
14	11	24652	NUT, STARTER SOLENOID SCRE	2		
15	10	26632	SCREW, ELECTRIC PANEL TO C	1		
16	10	35787	SCREW, ELECTRIC PANEL TO C	1		
17	10	47954	SCREW, ELECTRIC PANEL TO C	1		
18	13	35048	LOCKWASHER, ELECTRIC PANE	3		
19	12	20553	WASHER, ELECTRIC PANEL SCF	3		
20	25	47625	GROMMET, ELECTRIC PANEL	1		
21	332	2986A 3	SWITCH BOX ASSEMBLY	1		
22	12	45075	WASHER, SWITCH BOX TERMI	7		
23	13	26996	LOCKWASHER, SWITCH BOX TE	7		
24	11	45076	NUT, SWITCH BOX TERMINAL	7		
25	10	26184	SCREW, SWITCH BOX TO ELECT	4		
26	13	21547	LOCKWASHER, SWITCH BOX SC	4		
27	10	45218	SCREW, GROUND WIRE TO SWI	1		
28		37707	VOLTAGE REGULATOR	1,1		
29	10	52102	SCREW, VOLTAGE REGULATOR	3		
30	13	26992	LOCKWASHER, VOLTAGE REGU	3		
29	10	37908	SCREW, VOLTAGE REGULATOR	,3		
30	12	20028	WASHER, VOLTAGE REGULATO	,3		
31	332	2983A 6	IGNITION COIL ASSEMBLY	1		
32	10	45102	SCREW, IGNITION COIL CLAMP	1		
32	10	45103	SCREW, IGNITION COIL CLAMP	1		
33	12	37407	WASHER, IGNITION COIL SCRE	1		
34	54	22740	CLIP, IGNITION COIL LEAD	1		
35		22789	"D" WASHER, IGNITION COIL S	1		