


AUTOLITE



					Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote	
1		58015A 2	DISTRIBUTOR ASSEMBLY, COM	1			
1		58016A 1	DISTRUBUTOR ASSEMBLY, COI	1			
2	393	4988	CAP, DISTRIBUTOR	1			
2	37	54675	DECAL, DISTRIBUTOR CAP	1			
3		65864	ROTOR	1			
4		58027	RETAINER, CAM TO SHAFT	1			
5	10	58018	SCREW, BREAKER AND COND	4			
6		58034	CONDENSER	1			
7		58033	BREAKER ASSEMBLY	1			
8	12	26994	WASHER, PRIMARY TERMINAL	2			
9	11	58019	NUT, PRIMARY TERMINAL	2			
10		58017	LEAD ASSEMBLY, PRIMARY TE	1			
11		58031	CLAMP, DISTRIBUTOR CAP AT	2			
12	17	58032	PIN, CLAMP TO DISTRIBUTOR	2			
13		58022	COLLAR, THRUST	1			
14	43	58023	GEAR, DRIVE (LEFT HAND CRA	1			
14	43	58024	GEAR, DRIVE (RIGHT HAND CF	1			
15	17	58021	PIN, THRUST COLLAR AND DR	2			
16	27	58025	GASKET, DISTRIBUTOR	1		4	
17		58258	CLAMP, DISTRIBUTOR TO INTAK	1			
18	10	58259	SCREW, DISTRIBUTOR CLAMP A	1			
19	13	58260	LOCKWASHER, DISTRIBUTOR C	1			
20		60335	LEAD ASSEMBLY, DISTRIBUTOR	1			
21		26433	COIL, IGNITION	1			
22		33321	BRACKET, IGNITION COIL MOUN	1			
23	10	33311	SCREW, BRACKET TO IGNITION	1			
24	13	35048	LOCKWASHER, IGNITION COIL T	1			
25	12	30164	WASHER, IGNITION COIL TERMI	2			
26	13	26996	LOCKWASHER, IGNITION COIL T	2			
27	11	20645	NUT, IGINATION COIL TERMINAL	2			
28	10	34613	SCREW, IGNITION COIL ATTACH	1			
29	12	20553	WASHER, IGNITION COIL ATTA	1			
30	23	60339	SPACER, IGNITION COIL ATTACH	1			
31		47861A11	LEAD ASSEMBLY, HIGH TENSIO	1			
31		47861A12	LEAD ASSEMBLY, HIGH TENSIO	1			
31		47861A 9	LEAD ASSEMBLY, HIGH TENSIO	1			
31		47861A 5	LEAD ASSEMBLY, HIGH TENSIO	1			
31		47861A 6	LEAD ASSEMBLY, HIGH TENSIO	2			
31		47861A13	LEAD ASSEMBLY, HIGH TENSIO	1			
31		47861A 8	LEAD ASSEMBLY, HIGH TENSIO	1			
32		47861A 1	PROTECTOR, SPARK PLUG	1			