



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		59497A	1 THERMOSTAT HOUSING ASSEM	1	SERIAL 00000000-03693272	
1		63588A	1 THERMOSTAT HOUSING ASSEM	1	SERIAL 03750508-09999999	
2	23	54476	SLEEVE, THERMOSTAT HOUSI	1		
3	10	54523	SCREW, HOUSING TO INTAKE M	1		
3	10	35386	SCREW, HOUSING TO INTAKE M	1		
4	12	20084	WASHER, THERMOSTAT HOUSI	2		
5	27	54506	GASKET, THERMOSTAT HOUSIN	1		4
6		59137	THERMOSTAT	1		
7		59498	COVER, THERMOSTAT	1		
7		62898	COVER, THERMOSTAT (MC 225-S	1		
8	27	60208	GASKET, THERMOSTAT COVER	1		4
9	10	24234	SCREW, THERMOSTAT COVER	3		
10	13	39107	LOCKWASHER, THERMOSTAT C	3		
11	32	54570	HOSE, THERMOSTAT HOUSING	1		
12	24	32781	CLAMP, HOSE TO THERMOSTAT	2		
13	32	54906	HOSE, HERMOSTAT HSG. TO W	1		
13	32	58466	HOSE, THERMOSTAT HOUSING	1	SERIAL 00000000-03416390	
13	32	64815	HOSE, THERMOSTAT HOUSING	1	SERIAL 03563182-09999999	
13	32	63576A	1 HOSE ASSEMBLY, THERMOSTA	1		
14	54	64488	CLAMP, HOSE ATTACHING MC 2	1		
14	54	64489	CLAMP, HOSE ATTACHING MC 2	2		
15	54	32780	CLAMP, HOSE ATTACHING MC 2	2		
16		62895	ELBOW, EXHAUST (STARBOARD	1		
16		62894	ELBOW, EXHAUST (PORT SIDE)	1		
17	10	58640	SCREW, EXHAUST ELBOW TO T	6		
18	13	35048	LOCKWASHER, EXHAUST ELBO	6		
19		53821	BELLOWS, EXHAUST ELBOW M	2		
20	54	33683	CLAMP, BELLOWS TO EXHAUST	8		
21	25	35029	"O" RING, EXHAUST ELBOW TO	2		
22		60930	WATER SHUTTER, EXHAUST EL	2		
23		63151	RETAINER, SHUTTER TO EXHAL	2		
16		59824	ELBOW, EXHAUST MC 225-S	2		
17	10	60992	SCREW, EXHAUST ELBOW TO E	6		
18	13	35048	LOCKWASHER, EXHAUST ELBO	6		
19		53821	BELLOWS, EXHAUST ELBOW M	2		
20	54	33683	CLAMP, BELLOW TO EXHAUST E	6		
21	25	35029	"O" RING, EXHAUST ELBOW TO	2		
22		60930	SHUTTER, WATER EXHAUST SE	2		
23		60931	RETAINER, WATER SHUTTER M	2		
24		59825	SEPARATOR, EXHAUST MC 225	1		
25	10	60925	SCREW, EXHAUST SEPARATOR	1		