



**BREAKDOWN OF WATER PUMP**

B-46-63450A2



**MC II-TR and INBOARD**



**Parts List**

Ref	Class	Part	Description	Qty	Comment	Footnote
1	46	63450A 2	WATER PUMP ASSEMBLY, COM	1		
2		59155	COVER, WATER PUMP	1		
3		28635	SCREW, WATER PUMP COVE	6		
4	25	59712	"O" RING, WATER PUMP COVE	1		
5	19	59504	PLUG, IMPELLER	1		
6	47	59362A 1	IMPELLER ASSEMBLY	1		
7	28	56662	KEY, IMPELLER DRIVE	2		
8		59363A 1	CAM SEGMENT ASSEMBLY, W	1		
9	10	60777	SCREW, CAM SEGMENT ATTAI	1		
10		59503	WEAR PLATE	2		
11	23	47511	SLEEVE, WATER PUMP COVE	2		
12	26	23300	OIL SEAL, WATER PUMP SHAF	2		
13	30	20861	BALL BEARING, WATER PUMP	2		
14		59501	SHAFT, WATER PUMP	1		
15	53	23720	RING, SNAP - BALL BEARING R	1		
16	26	59564	OIL SEAL, WATER PUMP SHAF	1		
17		47530	HUB, WATER PUMP PULLEY	1		
18		59762	PULLEY, WATER PUMP	1		
19	10	20705	SCREW, WATER PUMP PULLEY	4		
20	13	39107	LOCKWASHER, WATER PUMP P	4		
21	32	62010	HOSE, PUMP TO OIL COOLER IN	1		
22	54	32780	CLAMP, WATER PUMP HOSE INE	2		
23		61990	STA STRAP, HOSE ATTACHING	2		
24		61860	BRACKET, WATER PUMP ADJUST	1		
24		54478	BRACE, WATER PUMP ADJUSTII	1		
25	10	35353	SCREW, ADJUSTING BRACE TO	1		
26	13	35048	LOCKWASHER, ADJUSTING BRA	1		
27	12	34714	WASHER, ADJUSTING BRACE SI	1		
28	10	37612	SCREW, ADJUSTING BRACE TO	2		
28	10	26632	SCREW, ADJUSTING BRACE TO	1		
29	12	34714	WASHER, ADJUSTING BRACE SI	2		
29	12	20553	WASHER, ADJUSTING BRACE SI	1		
30	13	35048	LOCKWASHER, ADJUSTING BRA	1		
31	11	32219	NUT, ADJUSTING BRACE SCREW	2		
31	11	28517	NUT, ADJUSTING BRACE SCREW	1		
32		49581	BRACKET, WATER PUMP	1		
33	10	34354	SCREW, WATER PUMP BRACKE	1		
34	13	35048	LOCKWASHER, WATER PUMP B	1		
35	10	52409	SCREW, WATER PUMP BRACKE	1		
36	23	33186	BUSHING, WATER PUMP BRACK	1		
37	11	22161	NUT, WATER PUMP BRACKET S	1		