



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	57	57298	V' BELT, HYDRAULIC PUMP DRI	1		
2		56331A 1	PULLEY ASSEMBLY, CRANKSHA	1		
3	10	52693	SCREW, PULLEY TO CRANKSH	3		
4	13	35048	LOCKWASHER, PULLEY SCREW	3		
5	12	20553	WASHER, PULLEY SCREW	3		
6		49181	PULLEY, HYDRAULIC PUMP	1		
7	12	21901	WASHER, PULLEY TO HYDRAUL	1		
8	11	25899	NUT, PULLEY TO HYDRAULIC PL	1		
9		56313	BRACKET, HYDRAULIC PUMP M	1		
10	10	47462	SCREW, PUMP MOUNTING BRA	2		
11	13	37272	LOCKWASHER, PUMP MOUNTIN	2		
12	10	37612	SCREW, HYDRAULIC PUMP TO	1		
13	10	34354	SCREW, HYDRAULIC PUMP TO	1		
14	13	37459	LOCKWASHER, HYDRAULIC PUN	2		
15	12	25909	WASHER, HYDRAULIC PUMP SC	2		
16	23	57369	SPACER, HYDRAULIC PUMP SCF	1		
17		63005	BRACE, HYDRAULIC PUMP	1		
18	10	34353	SCREW, BRACE TO HYDRAULIC	1		
19	13	35048	LOCKWASHER, BRACE SCREW	2		
20	12	34714	WASHER, BRACE SCREW	1		
21		62649	OIL COOLER	1	SERIAL 00000000-03386129	
21		64865	OIL COOLER	1	SERIAL 03523080-09999999	
22	32	57231	HOSE, OIL COOLER TO THERMO	1	SERIAL 00000000-03386120	
23	32	57230	HOSE, OIL COOLER TO WATER F	1	SERIAL 00000000-03386120	
22	32	64917	HOSE, OIL COOLER TO THERMO	1	SERIAL 03523080-09999999	
23	32	62010	HOSE, OIL COOLER TO WATER F	1	SERIAL 03523080-09999999	
24	54	32780	CLAMP, HOSE ATTACHING	4		
25	54	64324	CLAMP, HOSE ATTACHING TO O	2		
26		62870	BRACKET, OIL COOLER	1	SERIAL 00000000-03386120	
26		64864	BRACKET, OIL COOLER	1	SERIAL 03523080-09999999	
27		56328	BRACKET, CLAMP - OIL COOLER	1		
28	10	21625	SCREW, CLAMP BRACKET TO OI	2		
29	11	20361	NUT, CLAMP BRACKET SCREW	2	SERIAL 00000000-03386120	
30		62871	PLATE, MOUNTING - OIL COOLE	1	SERIAL 00000000-03386120	
31	10	57357	SCREW, MOUNT PLATE TO ENG	1	SERIAL 00000000-03386120	
32	12	34567	WASHER, MOUNT PLATE SCREW	2	SERIAL 00000000-03386120	
33	10	26065	SCREW, OIL COOLER BRACKET	1	SERIAL 00000000-03386120	
34	12	26825	WASHER, OIL COOLER BRACKET	2	SERIAL 00000000-03386120	
35	11	35814	NUT, OIL COOLER BRACKET SCF	1	SERIAL 00000000-03386120	