



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		59497A	1 THERMOSTAT HOUSING ASSEM	1	SERIAL 00000000-03693272	
1		63588A	1 THERMOSTAT HOUSING ASSEM	1	SERIAL 03750508-09999999	
1	23	54476	1 SLEEVE, THERMOSTAT HOUSI	1		
2	10	54523	1 SCREW, HOUSING TO INTAKE M	1		
3	10	35386	1 SCREW, HOUSING TO INTAKE M	1		
4	12	20084	2 WASHER, THERMOSTAT HOUSI	2		
5	27	54506	1 GASKET, THERMOSTAT HOUSIN	1		4
6		59137	1 THERMOSTAT	1		
7		59498	1 COVER, THERMOSTAT	1		
7		62898	1 COVER, THERMOSTAT (MC 225-S	1		
8	27	60208	1 GASKET, THERMOSTAT COVER	1		4
9	10	24234	3 SCREW, THERMOSTAT COVER	3		
10	13	39107	3 LOCKWASHER, THERMOSTAT C	3		
11	32	54570	1 HOSE, THERMOSTAT HOUSING	1		
12	24	32781	2 CLAMP, HOSE TO THERMOSTAT	2		
13	32	54906	1 HOSE, HERMOSTAT HSG. TO W	1		
13	32	58466	1 HOSE, THERMOSTAT HOUSING	1	SERIAL 00000000-03416390	
13	32	64815	1 HOSE, THERMOSTAT HOUSING	1	SERIAL 03563182-09999999	
13	32	63576A	1 HOSE ASSEMBLY, THERMOSTA	1		
14	54	64488	2 CLAMP, HOSE ATTACHING MC 2	2		
14	54	64489	2 CLAMP, HOSE ATTACHING MC 2	2		
15	54	32780	2 CLAMP, HOSE ATTACHING MC 2	2		
16		62895	1 ELBOW, EXHAUST (STARBOARD	1		
16		62894	1 ELBOW, EXHAUST (PORT SIDE)	1		
17	10	58640	6 SCREW, EXHAUST ELBOW TO T	6		
18	13	35048	6 LOCKWASHER, EXHAUST ELBO	6		
19		53821	2 BELLOWS, EXHAUST ELBOW M	2		
20	54	33683	8 CLAMP, BELLOWS TO EXHAUST	8		
21	25	35029	2 "O" RING, EXHAUST ELBOW TO	2		
22		60930	2 WATER SHUTTER, EXHAUST EL	2		
23		63151	2 RETAINER, SHUTTER TO EXHAL	2		
16		59824	2 ELBOW, EXHAUST MC 225-S	2		
17	10	60992	6 SCREW, EXHAUST ELBOW TO E	6		
18	13	35048	6 LOCKWASHER, EXHAUST ELBO	6		
19		53821	2 BELLOWS, EXHAUST ELBOW M	2		
20	54	33683	6 CLAMP, BELLOW TO EXHAUST E	6		
21	25	35029	2 "O" RING, EXHAUST ELBOW TO	2		
22		60930	2 SHUTTER, WATER EXHAUST SE	2		
23		60931	2 RETAINER, WATER SHUTTER M	2		
24		59825	1 SEPARATOR, EXHAUST MC 225	1		
25	10	60925	1 SCREW, EXHAUST SEPARATOR	1		