



A-11

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		86246	FULE PUMP ASSEMBLY	1		
2	27	34213	GASKET, FUEL PUMP TO CYLINE	1		
3	10	35374	SCREW, FUEL PUMP TO MOUNT	2		
4		35373	PLATE, FUEL PUMP MOUNTING	1		
5	27	34898	GASKET, FUEL PUMP MOUNTING	1		
6	10	34277	SCREW, FUEL PUMP MOUNTING	2		
7		35377	ROD, PUSH - FUEL PUMP	1		
8	22	32876	NIPPLE, SIGHT GLASS TO FUEL	1		
9		47816	SIGHT GLASS	1		
10	35	60494	FUEL FILTER	1		
11		55481	BASE, FUEL FILTER	1		
12	22	36382	PLUG, PIPE - FUEL FILTER	1		
12	22	20025	PLUG, PIPE - FUEL FILTER (SLOT)	1		
13		77453	BRACKET, MOUNTING - FUEL FIL	1		
14	10	26066	SCREW, FUEL FILTER TO MOUN	2		
15	12	20084	WASHER, FUEL FILTER SCREW	2		
16	11	35814	NUT, FUEL FILTER SCREW	2		
17	22	33821	ELBOW, FUEL LINE TO FUEL PUI	3		
18	32	71325	FUEL LINE, FUEL FILTER TO FUE	1		
19	32	71326	FUEL LINE, FUEL PUMP TO CAR	1		
19	32	62874	FUEL LINE, FUEL PUMP TO CAR	1		