



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
1		54951A	2 REVERSE LOCK VALVE ASSEMB	1		
2	22	48166	FITTING, STRAIGHT - REVERSI	1		
3	22	52666	ELBOW, REVERSE LOCK VALV	1		
4	10	22485	SCREW, REVERSE LOCK VALVE	2		
5	12	20583	WASHER, REVERSE LOCK VALV	2		
6	11	46887	NUT, REVERSE LOCK VALVE SCI	2		
7		69392	SHIFT ACTUATOR ASSEMBLY(SE	1		
8		63038	COVER, SHIFT ACTUATOR	1		
9	12	22887	WASHER, TERMINAL BLOCK ANI	4		
10	13	26996	LOCKWASHER, TERMINAL BLOC	2		
11	11	20645	NUT, TERMINAL BLOCK AND CO'	2		
12	86	62993	TERMINAL BLOCK, MOUNTING B	1		
13	10	24233	SCREW, TERMINAL BLOCK AND	2		
14	13	26996	LOCKWASHER, TERMINAL BLOC	2		
15	23	61526	SPACER, TERMINAL BLOCK AND	2		
16	11	24656	NUT, TERMINAL BLOCK AND CO'	2		
17	10	36046	SCREW, HARNESS TO TERMINA	3		
18		62745A	1 BRACKET ASSEMBLY, MOUNTIN	1		
19	10	69028	SCREW, STOP (3/4")	1		
20	11	46887	NUT, STOP SCREW	1		
21	10	34290	SCREW, SHIFT ACTUATOR TO M	3		
22	13	26992	LOCKWASHER, SHIFT ACTUATO	3		
23	84	70958A	1 SWITCH ASSEMBLY, CUT-OUT	1		
24	10	30902	SCREW, SWITCH TO CONTROL	2		
25	10	25299	SCREW, MOUNTIN BRACKET TO	4		
26	13	39107	LOCKWASHER, CONTROL VALVE	4		