



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		76773A	FLYWHEEL HOUSING ASSEMBLY	1		
2		33149	MOUNT, RUBBER - FLYWHEEL	2		
3	23	46742	SPACER, RUBBER MOUNT - FL	2		
4	10	26632	SCREW, FLYWHEEL HOUSING A	5		
4	10	45754	SCREW, FLYWHEEL HOUSING A	1		
5	13	37459	LOCKWASHER, FLYWHEEL HOU	6		
5	12	20572	WASHER, FLYWHEEL HOUSING	1		
6	16	64066	STUD, FLYWHEEL HOUSING AT	1		
7	11	32219	NUT, FLYWHEEL HOUSING STUI	1		