



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		86246	FUEL PUMP (USE WITH SIGHT G	1		
1		97401	FUEL PUMP (USE WITH SIGHT T	1		
1A	32	73815	TUBE, SIGHT, PUMP TO CARBUF	1		
2	27	34213	GASKET, FUEL PUMP TO CYLINE	1		3
3	10	34354	SCREW, FUEL PUMP TO MOUNT	2		
3A	13	35048	LOCKWASHER, FUEL PUMP SCR	2		
4		35373	PLATE, FUEL PUMP MOUNTING	1		
5	27	34898	GASKET, FUEL PUMP MOUNTING	1		3
6	10	34277	SCREW, FUEL PUMP MOUNTING	2		
7		35377	ROD, PUSH-FUEL PUMP	1		
8	22	32876	NIPPLE, SIGHT GLASS TO FUEL	1		
9		47816	SIGHT GLASS	1		
10	35	60494A	FUEL FILTER	1		
11		89876	BASE, FUEL FILTER	1		
12	22	20025	PLUG, PIPE-FUEL FILTER (SLOT)	2		
13		77453	BRACKET, MOUNTING-FUEL FIL	1		
14	10	26066	SCREW, FUEL FILTER TO MOUN	2		
15	12	20084	WASHER, FUEL FILTER SCREW	2		
16	11	35814	NUT, FUEL FILTER SCREW	2		
17	22	33821	ELBOW, FILTER TO PUMP AND F	3		
18	32	71325	FUEL LINE, FILTER TO PUMP US	1		
19	32	71326	FUEL LINE, FUEL PUMP TO CAR	1		
18	32	97384	FUEL LINE, FILTER TO PUMP	1	USE WITH SIGHT TUBE (V DRIV	
19	32	96081	FUEL LINE, FUEL PUMP TO CAR	1	USE WITH SIGHT TUBE (V DRIV	
19	32	62874	FUEL LINE, FUEL PUMP TO CAR	1		
20	12	53705	WASHER, FUEL FILTER BRACKE	2		