

Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		71317A 8	HYDRAULIC PUMP ASSEMBLY, F	1	
1		90507A 1	HYDRAULIC PUMP ASSEMBLY, F	1	
2		38333	CAP, FILLER- HYDRAULIC PUM	1	
2A		73873	PULLEY, HYDDRAULIC PUMP	1	
3	32	65929	HOSE, RETURN - VALVE TO OIL	1	
3A	32	65231	HOSE, RETURN- OIL COOLER TC	1	
4	54	35830	CLAMP, RETURN HOSE TO HYDI	3	
5	32	55116	HOSE, PRESSURE- POWER STE	1	
5	32	90494	HOSE, PRESSURE- POWER STE	1	
6		61990	STA-STRAP, HYDRAULIC HOSES	1	
7		57969	CYLINDER, BOOSTER (B-25-5822	1	
8		26059	CAP, RUBBER- BOOSTER CYLIN	1	
9	32	57633	TUBE, EXTENDING- POWER STE	1	
10	32	57634	TUBE, RETRACTING- POWER ST	1	
11		52779A 2	VALVE, POWER STEERING 9B-2	1	
11A	22	67305	FITTING, GREASE - POWER STE	1	
12	16	55109	STUD, ADAPTER - POWER STEE	1	
13	10	37612	SCREW, CLAMPING (1 1/4")	1	
14	13	37459	LOCKWASHER, CLAMPING SCRE	1	
15	23	60773	SLEEVE, ADJUSTING- CABLE GU	1	
15A	23	60652	SLEEVE, ADJUSTING - CABLE GL	1	
16		55110	ADAPTER, CABLE GUIDE TUBE (	1	
17	13	20897	LOCKWASHER, DUAL ADAPTER	1	
18	11	55111	NUT, DUAL ADAPTER TO POWE	1	
19	32	55112	TUBE, CABLE GUIDE	1	
20	12	37985	WASHER, CABLE GUIDE TUBE	2	
21	11	37984	NUT, CABLE GUIDE TUBE	2	
22		64414	GUIDE, CABLE GUIDE TUBE	1	
23		57286	BRACKET, MOUNTING - TRANSC	1	
24	10	31832	SCREW, MOUNTING BRACKET T	2	
25	13	31848	LOCKWASHER, MOUNTING BRA	2	
26	10	57968	SCREW, ADJUSTING - MOUNTIN	1	
27	13	37459	LOCKWASHER, ADJUSTING SCR	1	
28	11	24883	NUT, ADJUSTING SCREW	1	
29	12	20959	WASHER, VALVE ADAPTOR STU	1	
30	11	28040	NUT, VALVE ADAPTOR STUD	1	
31	11	32882	NUT, MOUNTING TUBE	1	
32		57971	TUBE, MOUNTING - BOOSTER R	1	
32A	24	78498	SPRING, TORSION - MOUNTING	1	
33	11	55983	NUT, JAM - MOUNTING TUBE	1	
34		57970	EXTENSION, CYLINDERS BOOST	1	

