



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	84	86676A	2 WIRING HARNESS (STERN DRIV	1	SERIAL 00000000-#5875713	
1	84	93177A	1 WIRING HARNESS (STERN DRIV	1	SERIAL #5875714-09999999	
1	84	86677A	2 WIRING HARNESS (INBOARD)	1		
2		26079	1 PLATE, WIRING HARNESS TO M	1		
3	10	46718	4 SCREW, WIRING HARNESS PLA	4		
4		77440	1 BRACKET, MOUNTING STERN D	1		
5	10	34354	2 SCREW, MOUNTING BRACKET A	2		
6	13	35048	2 LOCKWASHER, MOUNTING BRA	2		
4		87090	1 BRACKET, MOUNTING INBOARD	1		
5	10	47461	2 SCREW, MOUNTING BRACKET A	2		
6	13	32993	2 LOCKWASHER, MOUNTING BRA	2		
8		64884	1 TAB, WIRING HARNESS	1		
9	89	76416A	1 STARTER SOLENOID STERN DR	1		
10	10	69028	2 SCREW, STARTER SOLENOID TI	2		
11	11	20361	2 NUT, STARTER SOLENOID SCRE	2		
9	89	68258	1 STARTER SOLENOID INBOARD	1		
10	10	69054	2 SCREW, STARTER SOLENOID TI	2		
12	13	26992	2 LOCKWASHER, STARTER SOLEI	2		
13	13	26996	2 LOCKWASHER, STARTER SOLEI	2		
14	11	68219	2 NUT, STARTER SOLENOID TERM	2		
15	13	26993	2 LOCKWASHER, STARTER SOLEI	2		
16	11	68292	2 NUT, STARTER SOLENOID TERM	2		
17	88	78813	1 CIRCUIT BREAKER, 40 AMP	1		
18	13	26996	1 LOCKWASHER, CIRCUIT BREA	1		
19	11	68219	1 NUT, CIRCUIT BREAKER TERM	1		
20	10	24637	2 SCREW, CIRCUIT BREAKER TO	2		
24	12	30164	2 WASHER, CIRCUIT BREAKER SC	2		
25	11	46438	2 NUT, CIRCUIT BREAKER SCREW	2		
26		45915	1 TERMINAL BLOCK, ROTARY TRII	1		
27	10	62568	1 SCREW, ROTARY TRIM SENDEF	1		
28	10	29240	1 SCREW, TERMINAL BLOCK (5/8"	1		
29	11	46438	1 NUT, TERMINAL BLOCK SCREW	1		
30	84	78581A	2 WIRING HARNESS, ALTERNATO	1	USED WITH FUSED ENGINES O	
30	84	78581A	3 WIRING HARNESS, ALTERNATO	1	USED WITH FUSED ENGINES O	
31		57908	2 SLEEVE, WIRING HARNESS	2		
32		61990	3 STA-STRAP, WIRING HARNESS	3		
33	54	78945	1 "J" CLIP, IGNITION LEADS	1		
33	54	78944	1 "J" CLIP, STARTER LEADS	1		
33	54	73668	1 "J" CLIP, MAIN HARNESS LEADS	1		
33	54	54178	1 "J" CLIP, TEMPERATURE SENDE	1		
34	10	26702	1 SCREW, "J" CLIP ATTACHING O	1		