



BREAKDOWN OF WATER PUMP



PLASTIC BODY



B-7

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	46	72774A11	WATER PUMP ASSEMBLY	1		
1A	46	7525774	WATER PUMP BODY	1		
2		72776	COVER, WATER PUMP	1		
3	10	28642	SCREW, WATER PUMP SLEEVE	4		
4	10	63328	SCREW, COVER TO BODY (3")	5		
5	12	20084	WASHER, CPVER TP BPOU SC	5		
6	27	72779	GASKET, COVER TO OUTER W	1		
7		72777	WEAR PLATE	1		
8	27	72780	GASKET, BODY TO WEAR PLA	2		
9	19	59504	PLUG, IMPELLER	1		
11	28	56662	KEY, IMPELLER DRIVE	1		
12		72778	WEAR PLATE	1		
13	25	37340	"O" RING, PUMP HOUSING TO	1		
14	46	71497A 2	PUMP HOUSING	1		
15	26	23300	OIL SEAL, WATER PUMP SH	2		
16	30	72961	BALL BEARING, WATER PUM	2		
17		59501	SHAFT, WATER PUMP	1		
18	53	23720	RING, SNAP - BALL BEARING	1		
19	26	72785	OIL SEAL, WATER PUMP SH	1		
20		47530	HUB, WATER PUMP SHAFT	1		
20		47530	HUB, WATER PUMP PULLEY	1		
21		73798	PULLEY, WATER PUMP	1		
22		58265	BLAMPING RING, PUMP PULLEY	1		
23	10	47277	SCREW, PULLEY TO WATER PU	4		
24	13	39107	LOCKWASHER, WATER PUMP P	4		
25	32	72837	HOSE, WATER PUMP TO OIL CO	1		
25	32	49044	HOSE, PUMP TO THERMOSTAT	1		
26	54	32780	CLAMP, WATER PUMP HOSE	2		
27		62711	STA-STRAP, HOSE ATTACHING	1		
28		47488	BRACKET, WATER PUMP	1		
29	10	34354	SCREW, WATER PUMP BRACKE	1		
30	13	35048	LOCKWASHER, WATER PUMP B	1		
31	10	34353	SCREW< WATER PUMP BRACKE	2		
32	13	35048	LOCKWASHER, WATER PUMP B	2		
33	12	34714	WASHER, WATER PUMP BRACK	1		
34		76739	BRACE, WATER PUMP ADJUSTII	1		
34		71648	BRACE, WATER PUMP ADJUSTII	1		
35	10	34353	SCREW, BRACE TO STEERING F	1		
35	10	76926	SCREW, BRACE TO STEERING F	1		
36	13	35048	LOCKWASHER, ADJUSTING BRA	1		
37	12	24714	WASHER, ADJUSTING BRACE SC	1		