



MCM 228 and MCM 228 TR

| Parts List | | | | | | |
|------------|-------|-------|----------------------------|-----|--------------------------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | | 70938 | BRACKET, MOUNTING - ENGINE | 2 | SERIAL 00000000-9290290: | |
| 1 | | 79550 | BRACKET, MOUNTING - ENGINE | 2 | SERIAL 04929030-09999999 | |
| 2 | 10 | 37612 | SCREW, MOUNTING BRACKET T | 6 | | |
| 3 | 13 | 35048 | LOCKWASHER, MOUNTING BRA | 6 | | |
| 4 | | 66284 | BRACKET, MOUNTING | 2 | | |
| 5 | 11 | 20739 | NUT, JAM - MOUNTING BRACK | 4 | | |
| 6 | 13 | 68102 | LOCKWASHER, MOUNTING BRA | 2 | | |